

libATA Developer's Guide

Jeff Garzik

libATA Developer's Guide

by Jeff Garzik

Copyright © 2003-2006 Jeff Garzik

The contents of this file are subject to the Open Software License version 1.1 that can be found at <http://fedoraproject.org/wiki/Licensing:OSL1.1> and is included herein by reference.

Alternatively, the contents of this file may be used under the terms of the GNU General Public License version 2 (the "GPL") as distributed in the kernel source COPYING file, in which case the provisions of the GPL are applicable instead of the above. If you wish to allow the use of your version of this file only under the terms of the GPL and not to allow others to use your version of this file under the OSL, indicate your decision by deleting the provisions above and replace them with the notice and other provisions required by the GPL. If you do not delete the provisions above, a recipient may use your version of this file under either the OSL or the GPL.

Table of Contents

1. Introduction	1
2. libata Driver API	2
struct ata_port_operations	2
Disable ATA port	2
Post-IDENTIFY device configuration	2
Set PIO/DMA mode	2
Taskfile read/write	3
PIO data read/write	3
ATA command execute	3
Per-cmd ATAPI DMA capabilities filter	3
Read specific ATA shadow registers	3
Write specific ATA shadow register	4
Select ATA device on bus	4
Private tuning method	4
Control PCI IDE BMDMA engine	4
High-level taskfile hooks	5
Exception and probe handling (EH)	5
Hardware interrupt handling	6
SATA phy read/write	6
Init and shutdown	7
3. Error handling	8
Origins of commands	8
How commands are issued	8
How commands are processed	9
How commands are completed	9
ata_scsi_error()	10
Problems with the current EH	10
4. libata Library	12
ata_link_next	13
ata_dev_next	14
atapi_cmd_type	15
ata_tf_to_fis	16
ata_tf_from_fis	17
ata_pack_xfermask	18
ata_unpack_xfermask	19
ata_xfer_mask2mode	20
ata_xfer_mode2mask	21
ata_xfer_mode2shift	22
ata_mode_string	23
ata_dev_classify	24
ata_id_string	25
ata_id_c_string	26
ata_id_xfermask	27
ata_pio_need_iordy	28
ata_do_dev_read_id	29
ata_cable_40wire	30
ata_cable_80wire	31
ata_cable_unknown	32
ata_cable_ignore	33
ata_cable_sata	34
ata_dev_pair	35

sata_set_spd	36
ata_timing_cycle2mode	37
ata_do_set_mode	38
ata_wait_after_reset	39
sata_link_debounce	40
sata_link_resume	41
sata_link_scr_lpm	42
ata_std_prereset	43
sata_link_hardreset	44
sata_std_hardreset	45
ata_std_postreset	46
ata_dev_set_feature	47
ata_std_qc_defer	48
ata_sg_init	49
ata_qc_complete	50
ata_qc_complete_multiple	51
sata_scr_valid	52
sata_scr_read	53
sata_scr_write	54
sata_scr_write_flush	55
ata_link_online	56
ata_link_offline	57
ata_host_suspend	58
ata_host_resume	59
ata_host_alloc	60
ata_host_alloc_pinfo	61
ata_slave_link_init	62
ata_host_start	63
ata_host_init	64
ata_host_register	65
ata_host_activate	66
ata_host_detach	67
ata_pci_remove_one	68
ata_platform_remove_one	69
ata_msleep	70
ata_wait_register	71
sata_lpm_ignore_phy_events	72
5. libata Core Internals	73
ata_dev_phys_link	74
ata_force_cbl	75
ata_force_link_limits	76
ata_force_xfermask	77
ata_force_horkage	78
ata_rwcmd_protocol	79
ata_tf_read_block	80
ata_build_rw_tf	81
ata_read_native_max_address	82
ata_set_max_sectors	83
ata_hpa_resize	84
ata_dump_id	85
ata_exec_internal_sg	86
ata_exec_internal	87
ata_pio_mask_no_iordy	88
ata_dev_read_id	89

ata_dev_configure	90
ata_bus_probe	91
sata_print_link_status	92
sata_down_spd_limit	93
sata_set_spd_needed	94
ata_down_xfermask_limit	95
ata_wait_ready	96
ata_dev_same_device	97
ata_dev_reread_id	98
ata_dev_revalidate	99
ata_is_40wire	100
cable_is_40wire	101
ata_dev_xfermask	102
ata_dev_set_xfermode	103
ata_dev_init_params	104
ata_sg_clean	105
atapi_check_dma	106
ata_sg_setup	107
swap_buf_le16	108
ata_qc_new_init	109
ata_qc_free	110
ata_qc_issue	111
ata_phys_link_online	112
ata_phys_link_offline	113
ata_dev_init	114
ata_link_init	115
sata_link_init_spd	116
ata_port_alloc	117
ata_finalize_port_ops	118
ata_port_detach	119
6. libata SCSI translation/emulation	120
ata_std_bios_param	121
ata_scsi_unlock_native_capacity	122
ata_scsi_slave_config	123
ata_scsi_slave_destroy	124
__ata_change_queue_depth	125
ata_scsi_change_queue_depth	126
ata_scsi_queuecmd	127
ata_scsi_simulate	128
ata_sas_port_alloc	129
ata_sas_port_start	130
ata_sas_port_stop	131
ata_sas_async_probe	132
ata_sas_port_init	133
ata_sas_port_destroy	134
ata_sas_slave_configure	135
ata_sas_queuecmd	136
ata_get_identity	137
ata_cmd_ioctl	138
ata_task_ioctl	139
ata_scsi_qc_new	140
ata_dump_status	141
ata_to_sense_error	142
ata_gen_ata_sense	143

ataapi_drain_needed	144
ata_scsi_start_stop_xlat	145
ata_scsi_flush_xlat	146
scsi_6_lba_len	147
scsi_10_lba_len	148
scsi_16_lba_len	149
ata_scsi_verify_xlat	150
ata_scsi_rw_xlat	151
ata_scsi_translate	152
ata_scsi_rbuf_get	153
ata_scsi_rbuf_put	154
ata_scsi_rbuf_fill	155
ata_scsiop_inq_std	156
ata_scsiop_inq_00	157
ata_scsiop_inq_80	158
ata_scsiop_inq_83	159
ata_scsiop_inq_89	160
ata_scsiop_noop	161
modecpy	162
ata_msense_caching	163
ata_msense_control	164
ata_msense_rw_recovery	165
ata_scsiop_mode_sense	166
ata_scsiop_read_cap	167
ata_scsiop_report_luns	168
ataapi_xlat	169
ata_scsi_find_dev	170
ata_scsi_pass_thru	171
ata_format_dsm_trim_descr	172
ata_format_sct_write_same	173
ata_scsi_write_same_xlat	174
ata_scsiop_maint_in	175
ata_scsi_report_zones_complete	176
ata_mselect_caching	177
ata_mselect_control	178
ata_scsi_mode_select_xlat	179
ata_get_xlat_func	180
ata_scsi_dump_cdb	181
ata_scsi_offline_dev	182
ata_scsi_remove_dev	183
ata_scsi_media_change_notify	184
ata_scsi_hotplug	185
ata_scsi_user_scan	186
ata_scsi_dev_rescan	187
7. ATA errors and exceptions	188
Exception categories	188
HSM violation	188
ATA/ATAPI device error (non-NCQ / non-CHECK CONDITION)	188
ATAPI device CHECK CONDITION	190
ATA device error (NCQ)	190
ATA bus error	190
PCI bus error	191
Late completion	191
Unknown error (timeout)	191

Hotplug and power management exceptions	191
EH recovery actions	191
Clearing error condition	191
Reset	191
Reconfigure transport	193
8. ata_piix Internals	194
ich_pata_cable_detect	195
piix_pata_prereset	196
piix_set_piomode	197
do_pata_set_dmamode	198
piix_set_dmamode	199
ich_set_dmamode	200
piix_check_450nx_errata	201
piix_init_one	202
9. sata_sil Internals	203
sil_set_mode	204
sil_dev_config	205
10. Thanks	206

Chapter 1. Introduction

libATA is a library used inside the Linux kernel to support ATA host controllers and devices. libATA provides an ATA driver API, class transports for ATA and ATAPI devices, and SCSI<->ATA translation for ATA devices according to the T10 SAT specification.

This Guide documents the libATA driver API, library functions, library internals, and a couple sample ATA low-level drivers.

Chapter 2. libata Driver API

struct ata_port_operations is defined for every low-level libata hardware driver, and it controls how the low-level driver interfaces with the ATA and SCSI layers.

FIS-based drivers will hook into the system with ->qc_prep() and ->qc_issue() high-level hooks. Hardware which behaves in a manner similar to PCI IDE hardware may utilize several generic helpers, defining at a bare minimum the bus I/O addresses of the ATA shadow register blocks.

struct ata_port_operations

Disable ATA port

```
void (*port_disable) (struct ata_port *);
```

Called from ata_bus_probe() error path, as well as when unregistering from the SCSI module (rmmod, hot unplug). This function should do whatever needs to be done to take the port out of use. In most cases, ata_port_disable() can be used as this hook.

Called from ata_bus_probe() on a failed probe. Called from ata_scsi_release().

Post-IDENTIFY device configuration

```
void (*dev_config) (struct ata_port *, struct ata_device *);
```

Called after IDENTIFY [PACKET] DEVICE is issued to each device found. Typically used to apply device-specific fixups prior to issue of SET FEATURES - XFER MODE, and prior to operation.

This entry may be specified as NULL in ata_port_operations.

Set PIO/DMA mode

```
void (*set_piomode) (struct ata_port *, struct ata_device *);  
void (*set_dmamode) (struct ata_port *, struct ata_device *);  
void (*post_set_mode) (struct ata_port *);  
unsigned int (*mode_filter) (struct ata_port *, struct ata_device *, unsigned int);
```

Hooks called prior to the issue of SET FEATURES - XFER MODE command. The optional ->mode_filter() hook is called when libata has built a mask of the possible modes. This is passed to the ->mode_filter() function which should return a mask of valid modes after filtering those unsuitable due to hardware limits. It is not valid to use this interface to add modes.

dev->pio_mode and dev->dma_mode are guaranteed to be valid when ->set_piomode() and when ->set_dmamode() is called. The timings for any other drive sharing the cable will also be valid at this point. That is the library records the decisions for the modes of each drive on a channel before it attempts to set any of them.

->post_set_mode() is called unconditionally, after the SET FEATURES - XFER MODE command completes successfully.

->set_piomode() is always called (if present), but ->set_dma_mode() is only called if DMA is possible.

Taskfile read/write

```
void (*sff_tf_load) (struct ata_port *ap, struct ata_taskfile *tf);  
void (*sff_tf_read) (struct ata_port *ap, struct ata_taskfile *tf);
```

->tf_load() is called to load the given taskfile into hardware registers / DMA buffers. ->tf_read() is called to read the hardware registers / DMA buffers, to obtain the current set of taskfile register values. Most drivers for taskfile-based hardware (PIO or MMIO) use ata_sff_tf_load() and ata_sff_tf_read() for these hooks.

PIO data read/write

```
void (*sff_data_xfer) (struct ata_device *, unsigned char *, unsigned int, int);
```

All bmdma-style drivers must implement this hook. This is the low-level operation that actually copies the data bytes during a PIO data transfer. Typically the driver will choose one of ata_sff_data_xfer_noirq(), ata_sff_data_xfer(), or ata_sff_data_xfer32().

ATA command execute

```
void (*sff_exec_command)(struct ata_port *ap, struct ata_taskfile *tf);
```

causes an ATA command, previously loaded with ->tf_load(), to be initiated in hardware. Most drivers for taskfile-based hardware use ata_sff_exec_command() for this hook.

Per-cmd ATAPI DMA capabilities filter

```
int (*check_atapi_dma) (struct ata_queued_cmd *qc);
```

Allow low-level driver to filter ATA PACKET commands, returning a status indicating whether or not it is OK to use DMA for the supplied PACKET command.

This hook may be specified as NULL, in which case libata will assume that atapi dma can be supported.

Read specific ATA shadow registers

```
u8 (*sff_check_status)(struct ata_port *ap);  
u8 (*sff_check_altstatus)(struct ata_port *ap);
```

Reads the Status/AltStatus ATA shadow register from hardware. On some hardware, reading the Status register has the side effect of clearing the interrupt condition. Most drivers for taskfile-based hardware use `ata_sff_check_status()` for this hook.

Write specific ATA shadow register

```
void (*sff_set_devctl)(struct ata_port *ap, u8 ctl);
```

Write the device control ATA shadow register to the hardware. Most drivers don't need to define this.

Select ATA device on bus

```
void (*sff_dev_select)(struct ata_port *ap, unsigned int device);
```

Issues the low-level hardware command(s) that causes one of N hardware devices to be considered 'selected' (active and available for use) on the ATA bus. This generally has no meaning on FIS-based devices.

Most drivers for taskfile-based hardware use `ata_sff_dev_select()` for this hook.

Private tuning method

```
void (*set_mode) (struct ata_port *ap);
```

By default libata performs drive and controller tuning in accordance with the ATA timing rules and also applies blacklists and cable limits. Some controllers need special handling and have custom tuning rules, typically raid controllers that use ATA commands but do not actually do drive timing.

Warning

This hook should not be used to replace the standard controller tuning logic when a controller has quirks. Replacing the default tuning logic in that case would bypass handling for drive and bridge quirks that may be important to data reliability. If a controller needs to filter the mode selection it should use the `mode_filter` hook instead.

Control PCI IDE BMDMA engine

```
void (*bmdma_setup) (struct ata_queued_cmd *qc);  
void (*bmdma_start) (struct ata_queued_cmd *qc);  
void (*bmdma_stop) (struct ata_port *ap);  
u8   (*bmdma_status) (struct ata_port *ap);
```

When setting up an IDE BMDMA transaction, these hooks arm (`->bmdma_setup`), fire (`->bmdma_start`), and halt (`->bmdma_stop`) the hardware's DMA engine. `->bmdma_status` is used to read the standard PCI IDE DMA Status register.

These hooks are typically either no-ops, or simply not implemented, in FIS-based drivers.

Most legacy IDE drivers use `ata_bmdma_setup()` for the `bmdma_setup()` hook. `ata_bmdma_setup()` will write the pointer to the PRD table to the IDE PRD Table Address register, enable DMA in the DMA Command register, and call `exec_command()` to begin the transfer.

Most legacy IDE drivers use `ata_bmdma_start()` for the `bmdma_start()` hook. `ata_bmdma_start()` will write the `ATA_DMA_START` flag to the DMA Command register.

Many legacy IDE drivers use `ata_bmdma_stop()` for the `bmdma_stop()` hook. `ata_bmdma_stop()` clears the `ATA_DMA_START` flag in the DMA command register.

Many legacy IDE drivers use `ata_bmdma_status()` as the `bmdma_status()` hook.

High-level taskfile hooks

```
void (*qc_prep) (struct ata_queued_cmd *qc);
int (*qc_issue) (struct ata_queued_cmd *qc);
```

Higher-level hooks, these two hooks can potentially supercede several of the above taskfile/DMA engine hooks. `->qc_prep` is called after the buffers have been DMA-mapped, and is typically used to populate the hardware's DMA scatter-gather table. Most drivers use the standard `ata_qc_prep()` helper function, but more advanced drivers roll their own.

`->qc_issue` is used to make a command active, once the hardware and S/G tables have been prepared. IDE BMDMA drivers use the helper function `ata_qc_issue_prot()` for taskfile protocol-based dispatch. More advanced drivers implement their own `->qc_issue`.

`ata_qc_issue_prot()` calls `->tf_load()`, `->bmdma_setup()`, and `->bmdma_start()` as necessary to initiate a transfer.

Exception and probe handling (EH)

```
void (*eng_timeout) (struct ata_port *ap);
void (*phy_reset) (struct ata_port *ap);
```

Deprecated. Use `->error_handler()` instead.

```
void (*freeze) (struct ata_port *ap);
void (*thaw) (struct ata_port *ap);
```

`ata_port_freeze()` is called when HSM violations or some other condition disrupts normal operation of the port. A frozen port is not allowed to perform any operation until the port is thawed, which usually follows a successful reset.

The optional `->freeze()` callback can be used for freezing the port hardware-wise (e.g. mask interrupt and stop DMA engine). If a port cannot be frozen hardware-wise, the interrupt handler must ack and clear interrupts unconditionally while the port is frozen.

The optional `->thaw()` callback is called to perform the opposite of `->freeze()`: prepare the port for normal operation once again. Unmask interrupts, start DMA engine, etc.

```
void (*error_handler) (struct ata_port *ap);
```

`->error_handler()` is a driver's hook into probe, hotplug, and recovery and other exceptional conditions. The primary responsibility of an implementation is to call `ata_do_eh()` or `ata_bmdma_drive_eh()` with a set of EH hooks as arguments:

'prereset' hook (may be NULL) is called during an EH reset, before any other actions are taken.

'postreset' hook (may be NULL) is called after the EH reset is performed. Based on existing conditions, severity of the problem, and hardware capabilities,

Either 'softreset' (may be NULL) or 'hardreset' (may be NULL) will be called to perform the low-level EH reset.

```
void (*post_internal_cmd) (struct ata_queued_cmd *qc);
```

Perform any hardware-specific actions necessary to finish processing after executing a probe-time or EH-time command via `ata_exec_internal()`.

Hardware interrupt handling

```
irqreturn_t (*irq_handler)(int, void *, struct pt_regs *);  
void (*irq_clear) (struct ata_port *);
```

`->irq_handler` is the interrupt handling routine registered with the system, by libata. `->irq_clear` is called during probe just before the interrupt handler is registered, to be sure hardware is quiet.

The second argument, `dev_instance`, should be cast to a pointer to `struct ata_host_set`.

Most legacy IDE drivers use `ata_sff_interrupt()` for the `irq_handler` hook, which scans all ports in the `host_set`, determines which queued command was active (if any), and calls `ata_sff_host_intr(ap,qc)`.

Most legacy IDE drivers use `ata_sff_irq_clear()` for the `irq_clear()` hook, which simply clears the interrupt and error flags in the DMA status register.

SATA phy read/write

```
int (*scr_read) (struct ata_port *ap, unsigned int sc_reg,  
                u32 *val);  
int (*scr_write) (struct ata_port *ap, unsigned int sc_reg,  
                 u32 val);
```

Read and write standard SATA phy registers. Currently only used if `->phy_reset` hook called the `sata_phy_reset()` helper function. `sc_reg` is one of `SCR_STATUS`, `SCR_CONTROL`, `SCR_ERROR`, or `SCR_ACTIVE`.

Init and shutdown

```
int (*port_start) (struct ata_port *ap);  
void (*port_stop) (struct ata_port *ap);  
void (*host_stop) (struct ata_host_set *host_set);
```

->port_start() is called just after the data structures for each port are initialized. Typically this is used to alloc per-port DMA buffers / tables / rings, enable DMA engines, and similar tasks. Some drivers also use this entry point as a chance to allocate driver-private memory for ap->private_data.

Many drivers use ata_port_start() as this hook or call it from their own port_start() hooks. ata_port_start() allocates space for a legacy IDE PRD table and returns.

->port_stop() is called after ->host_stop(). Its sole function is to release DMA/memory resources, now that they are no longer actively being used. Many drivers also free driver-private data from port at this time.

->host_stop() is called after all ->port_stop() calls have completed. The hook must finalize hardware shutdown, release DMA and other resources, etc. This hook may be specified as NULL, in which case it is not called.

Chapter 3. Error handling

This chapter describes how errors are handled under libata. Readers are advised to read SCSI EH (Documentation/scsi/scsi_eh.txt) and ATA exceptions doc first.

Origins of commands

In libata, a command is represented with struct `ata_queued_cmd` or `qc`. `qc`'s are preallocated during port initialization and repetitively used for command executions. Currently only one `qc` is allocated per port but yet-to-be-merged NCQ branch allocates one for each tag and maps each `qc` to NCQ tag 1-to-1.

libata commands can originate from two sources - libata itself and SCSI midlayer. libata internal commands are used for initialization and error handling. All normal blk requests and commands for SCSI emulation are passed as SCSI commands through `queuecommand` callback of SCSI host template.

How commands are issued

Internal commands

First, `qc` is allocated and initialized using `ata_qc_new_init()`. Although `ata_qc_new_init()` doesn't implement any wait or retry mechanism when `qc` is not available, internal commands are currently issued only during initialization and error recovery, so no other command is active and allocation is guaranteed to succeed.

Once allocated `qc`'s taskfile is initialized for the command to be executed. `qc` currently has two mechanisms to notify completion. One is via `qc->complete_fn()` callback and the other is completion `qc->waiting`. `qc->complete_fn()` callback is the asynchronous path used by normal SCSI translated commands and `qc->waiting` is the synchronous (issuer sleeps in process context) path used by internal commands.

Once initialization is complete, `host_set` lock is acquired and the `qc` is issued.

SCSI commands

All libata drivers use `ata_scsi_queuecmd()` as `hostt->queuecommand` callback. `scmds` can either be simulated or translated. No `qc` is involved in processing a simulated `scmd`. The result is computed right away and the `scmd` is completed.

For a translated `scmd`, `ata_qc_new_init()` is invoked to allocate a `qc` and the `scmd` is translated into the `qc`. SCSI midlayer's completion notification function pointer is stored into `qc->scsidone`.

`qc->complete_fn()` callback is used for completion notification. ATA commands use `ata_scsi_qc_complete()` while ATAPI commands use `atapi_qc_complete()`. Both functions end up calling `qc->scsidone` to notify upper layer when the `qc` is finished. After translation is completed, the `qc` is issued with `ata_qc_issue()`.

Note that SCSI midlayer invokes `hostt->queuecommand` while holding `host_set` lock, so all above occur while holding `host_set` lock.

How commands are processed

Depending on which protocol and which controller are used, commands are processed differently. For the purpose of discussion, a controller which uses taskfile interface and all standard callbacks is assumed.

Currently 6 ATA command protocols are used. They can be sorted into the following four categories according to how they are processed.

ATA NO DATA or DMA	ATA_PROT_NODATA and ATA_PROT_DMA fall into this category. These types of commands don't require any software intervention once issued. Device will raise interrupt on completion.
ATA PIO	ATA_PROT_PIO is in this category. libata currently implements PIO with polling. ATA_NIEN bit is set to turn off interrupt and pio_task on ata_wq performs polling and IO.
ATAPI NODATA or DMA	ATA_PROT_ATAPI_NODATA and ATA_PROT_ATAPI_DMA are in this category. packet_task is used to poll BSY bit after issuing PACKET command. Once BSY is turned off by the device, packet_task transfers CDB and hands off processing to interrupt handler.
ATAPI PIO	ATA_PROT_ATAPI is in this category. ATA_NIEN bit is set and, as in ATAPI NODATA or DMA, packet_task submits cdb. However, after submitting cdb, further processing (data transfer) is handed off to pio_task.

How commands are completed

Once issued, all qc's are either completed with ata_qc_complete() or time out. For commands which are handled by interrupts, ata_host_intr() invokes ata_qc_complete(), and, for PIO tasks, pio_task invokes ata_qc_complete(). In error cases, packet_task may also complete commands.

ata_qc_complete() does the following.

1. DMA memory is unmapped.
2. ATA_QCFLAG_ACTIVE is cleared from qc->flags.
3. qc->complete_fn() callback is invoked. If the return value of the callback is not zero. Completion is short circuited and ata_qc_complete() returns.
4. __ata_qc_complete() is called, which does
 - a. qc->flags is cleared to zero.
 - b. ap->active_tag and qc->tag are poisoned.
 - c. qc->waiting is cleared & completed (in that order).
 - d. qc is deallocated by clearing appropriate bit in ap->qactive.

So, it basically notifies upper layer and deallocates qc. One exception is short-circuit path in #3 which is used by atapi_qc_complete().

For all non-ATAPI commands, whether it fails or not, almost the same code path is taken and very little error handling takes place. A qc is completed with success status if it succeeded, with failed status otherwise.

However, failed ATAPI commands require more handling as REQUEST SENSE is needed to acquire sense data. If an ATAPI command fails, `ata_qc_complete()` is invoked with error status, which in turn invokes `atapi_qc_complete()` via `qc->complete_fn()` callback.

This makes `atapi_qc_complete()` set `scmd->result` to `SAM_STAT_CHECK_CONDITION`, complete the `scmd` and return 1. As the sense data is empty but `scmd->result` is `CHECK_CONDITION`, SCSI midlayer will invoke EH for the `scmd`, and returning 1 makes `ata_qc_complete()` to return without deallocating the `qc`. This leads us to `ata_scsi_error()` with partially completed `qc`.

ata_scsi_error()

`ata_scsi_error()` is the current `transport->eh_strategy_handler()` for libata. As discussed above, this will be entered in two cases - timeout and ATAPI error completion. This function calls low level libata driver's `eng_timeout()` callback, the standard callback for which is `ata_eng_timeout()`. It checks if a `qc` is active and calls `ata_qc_timeout()` on the `qc` if so. Actual error handling occurs in `ata_qc_timeout()`.

If EH is invoked for timeout, `ata_qc_timeout()` stops BMDMA and completes the `qc`. Note that as we're currently in EH, we cannot call `scsi_done`. As described in SCSI EH doc, a recovered `scmd` should be either retried with `scsi_queue_insert()` or finished with `scsi_finish_command()`. Here, we override `qc->scsidone` with `scsi_finish_command()` and calls `ata_qc_complete()`.

If EH is invoked due to a failed ATAPI `qc`, the `qc` here is completed but not deallocated. The purpose of this half-completion is to use the `qc` as place holder to make EH code reach this place. This is a bit hackish, but it works.

Once control reaches here, the `qc` is deallocated by invoking `__ata_qc_complete()` explicitly. Then, internal `qc` for REQUEST SENSE is issued. Once sense data is acquired, `scmd` is finished by directly invoking `scsi_finish_command()` on the `scmd`. Note that as we already have completed and deallocated the `qc` which was associated with the `scmd`, we don't need to/cannot call `ata_qc_complete()` again.

Problems with the current EH

- Error representation is too crude. Currently any and all error conditions are represented with ATA STATUS and ERROR registers. Errors which aren't ATA device errors are treated as ATA device errors by setting ATA_ERR bit. Better error descriptor which can properly represent ATA and other errors/exceptions is needed.
- When handling timeouts, no action is taken to make device forget about the timed out command and ready for new commands.
- EH handling via `ata_scsi_error()` is not properly protected from usual command processing. On EH entrance, the device is not in quiescent state. Timed out commands may succeed or fail any time. `pio_task` and `atapi_task` may still be running.
- Too weak error recovery. Devices / controllers causing HSM mismatch errors and other errors quite often require reset to return to known state. Also, advanced error handling is necessary to support features like NCQ and hotplug.
- ATA errors are directly handled in the interrupt handler and PIO errors in `pio_task`. This is problematic for advanced error handling for the following reasons.

First, advanced error handling often requires context and internal `qc` execution.

Second, even a simple failure (say, CRC error) needs information gathering and could trigger complex error handling (say, resetting & reconfiguring). Having multiple code paths to gather information, enter EH and trigger actions makes life painful.

Third, scattered EH code makes implementing low level drivers difficult. Low level drivers override libata callbacks. If EH is scattered over several places, each affected callbacks should perform its part of error handling. This can be error prone and painful.

Chapter 4. libata Library

Name

`ata_link_next` — link iteration helper

Synopsis

```
struct ata_link * ata_link_next (struct ata_link * link, struct ata_port  
* ap, enum ata_link_iter_mode mode);
```

Arguments

link the previous link, NULL to start

ap ATA port containing links to iterate

mode iteration mode, one of ATA_LITER_*

LOCKING

Host lock or EH context.

RETURNS

Pointer to the next link.

Name

`ata_dev_next` — device iteration helper

Synopsis

```
struct ata_device * ata_dev_next (struct ata_device * dev, struct  
ata_link * link, enum ata_dev_iter_mode mode);
```

Arguments

dev the previous device, NULL to start

link ATA link containing devices to iterate

mode iteration mode, one of `ATA_DITER_*`

LOCKING

Host lock or EH context.

RETURNS

Pointer to the next device.

Name

`atapi_cmd_type` — Determine ATAPI command type from SCSI opcode

Synopsis

```
int atapi_cmd_type (u8 opcode);
```

Arguments

opcode SCSI opcode

Description

Determine ATAPI command type from *opcode*.

LOCKING

None.

RETURNS

`ATAPI_{READ|WRITE|READ_CD|PASS_THRU|MISC}`

Name

`ata_tf_to_fis` — Convert ATA taskfile to SATA FIS structure

Synopsis

```
void ata_tf_to_fis (const struct ata_taskfile * tf, u8 pmp, int is_cmd,  
u8 * fis);
```

Arguments

<i>tf</i>	Taskfile to convert
<i>pmp</i>	Port multiplier port
<i>is_cmd</i>	This FIS is for command
<i>fis</i>	Buffer into which data will output

Description

Converts a standard ATA taskfile to a Serial ATA FIS structure (Register - Host to Device).

LOCKING

Inherited from caller.

Name

`ata_tf_from_fis` — Convert SATA FIS to ATA taskfile

Synopsis

```
void ata_tf_from_fis (const u8 * fis, struct ata_taskfile * tf);
```

Arguments

fis Buffer from which data will be input

tf Taskfile to output

Description

Converts a serial ATA FIS structure to a standard ATA taskfile.

LOCKING

Inherited from caller.

Name

`ata_pack_xfermask` — Pack pio, mwdma and udma masks into xfer_mask

Synopsis

```
unsigned long ata_pack_xfermask (unsigned long pio_mask, unsigned long mwdma_mask, unsigned long udma_mask);
```

Arguments

pio_mask pio_mask

mwdma_mask mwdma_mask

udma_mask udma_mask

Description

Pack *pio_mask*, *mwdma_mask* and *udma_mask* into a single unsigned int xfer_mask.

LOCKING

None.

RETURNS

Packed xfer_mask.

Name

`ata_unpack_xfermask` — Unpack `xfer_mask` into pio, mwdma and udma masks

Synopsis

```
void ata_unpack_xfermask (unsigned long xfer_mask, unsigned long *  
pio_mask, unsigned long * mwdma_mask, unsigned long * udma_mask);
```

Arguments

<i>xfer_mask</i>	<code>xfer_mask</code> to unpack
<i>pio_mask</i>	resulting <code>pio_mask</code>
<i>mwdma_mask</i>	resulting <code>mwdma_mask</code>
<i>udma_mask</i>	resulting <code>udma_mask</code>

Description

Unpack *xfer_mask* into *pio_mask*, *mwdma_mask* and *udma_mask*. Any NULL destination masks will be ignored.

Name

`ata_xfer_mask2mode` — Find matching XFER_* for the given `xfer_mask`

Synopsis

```
u8 ata_xfer_mask2mode (unsigned long xfer_mask);
```

Arguments

xfer_mask `xfer_mask` of interest

Description

Return matching XFER_* value for *xfer_mask*. Only the highest bit of *xfer_mask* is considered.

LOCKING

None.

RETURNS

Matching XFER_* value, 0xff if no match found.

Name

`ata_xfer_mode2mask` — Find matching `xfer_mask` for `XFER_*`

Synopsis

```
unsigned long ata_xfer_mode2mask (u8 xfer_mode);
```

Arguments

xfer_mode `XFER_*` of interest

Description

Return matching `xfer_mask` for *xfer_mode*.

LOCKING

None.

RETURNS

Matching `xfer_mask`, 0 if no match found.

Name

`ata_xfer_mode2shift` — Find matching `xfer_shift` for `XFER_*`

Synopsis

```
int ata_xfer_mode2shift (unsigned long xfer_mode);
```

Arguments

xfer_mode `XFER_*` of interest

Description

Return matching `xfer_shift` for *xfer_mode*.

LOCKING

None.

RETURNS

Matching `xfer_shift`, -1 if no match found.

Name

`ata_mode_string` — convert `xfer_mask` to string

Synopsis

```
const char * ata_mode_string (unsigned long xfer_mask);
```

Arguments

xfer_mask mask of bits supported; only highest bit counts.

Description

Determine string which represents the highest speed (highest bit in *modemask*).

LOCKING

None.

RETURNS

Constant C string representing highest speed listed in *mode_mask*, or the constant C string “<n/a>”.

Name

`ata_dev_classify` — determine device type based on ATA-spec signature

Synopsis

```
unsigned int ata_dev_classify (const struct ata_taskfile * tf);
```

Arguments

tf ATA taskfile register set for device to be identified

Description

Determine from taskfile register contents whether a device is ATA or ATAPI, as per “Signature and persistence” section of ATA/PI spec (volume 1, sect 5.14).

LOCKING

None.

RETURNS

Device type, `ATA_DEV_ATA`, `ATA_DEV_ATAPI`, `ATA_DEV_PMP`, `ATA_DEV_ZAC`, or `ATA_DEV_UNKNOWN` the event of failure.

Name

`ata_id_string` — Convert IDENTIFY DEVICE page into string

Synopsis

```
void ata_id_string (const u16 * id, unsigned char * s, unsigned int  
ofs, unsigned int len);
```

Arguments

id IDENTIFY DEVICE results we will examine

s string into which data is output

ofs offset into identify device page

len length of string to return. must be an even number.

Description

The strings in the IDENTIFY DEVICE page are broken up into 16-bit chunks. Run through the string, and output each 8-bit chunk linearly, regardless of platform.

LOCKING

caller.

Name

`ata_id_c_string` — Convert IDENTIFY DEVICE page into C string

Synopsis

```
void ata_id_c_string (const u16 * id, unsigned char * s, unsigned int  
ofs, unsigned int len);
```

Arguments

id IDENTIFY DEVICE results we will examine

s string into which data is output

ofs offset into identify device page

len length of string to return. must be an odd number.

Description

This function is identical to `ata_id_string` except that it trims trailing spaces and terminates the resulting string with null. *len* must be actual maximum length (even number) + 1.

LOCKING

caller.

Name

`ata_id_xfermask` — Compute xfermask from the given IDENTIFY data

Synopsis

```
unsigned long ata_id_xfermask (const u16 * id);
```

Arguments

id IDENTIFY data to compute xfer mask from

Description

Compute the xfermask for this device. This is not as trivial as it seems if we must consider early devices correctly.

FIXME

pre IDE drive timing (do we care?).

LOCKING

None.

RETURNS

Computed xfermask

Name

`ata_pio_need_iordy` — check if iordy needed

Synopsis

```
unsigned int ata_pio_need_iordy (const struct ata_device * adev);
```

Arguments

adev ATA device

Description

Check if the current speed of the device requires IORDY. Used by various controllers for chip configuration.

Name

`ata_do_dev_read_id` — default ID read method

Synopsis

```
unsigned int ata_do_dev_read_id (struct ata_device * dev, struct
ata_taskfile * tf, u16 * id);
```

Arguments

dev device

tf proposed taskfile

id data buffer

Description

Issue the identify taskfile and hand back the buffer containing identify data. For some RAID controllers and for pre ATA devices this function is wrapped or replaced by the driver

Name

`ata_cable_40wire` — return 40 wire cable type

Synopsis

```
int ata_cable_40wire (struct ata_port * ap);
```

Arguments

ap port

Description

Helper method for drivers which want to hardwire 40 wire cable detection.

Name

`ata_cable_80wire` — return 80 wire cable type

Synopsis

```
int ata_cable_80wire (struct ata_port * ap);
```

Arguments

ap port

Description

Helper method for drivers which want to hardwire 80 wire cable detection.

Name

`ata_cable_unknown` — return unknown PATA cable.

Synopsis

```
int ata_cable_unknown (struct ata_port * ap);
```

Arguments

ap port

Description

Helper method for drivers which have no PATA cable detection.

Name

`ata_cable_ignore` — return ignored PATA cable.

Synopsis

```
int ata_cable_ignore (struct ata_port * ap);
```

Arguments

ap port

Description

Helper method for drivers which don't use cable type to limit transfer mode.

Name

`ata_cable_sata` — return SATA cable type

Synopsis

```
int ata_cable_sata (struct ata_port * ap);
```

Arguments

ap port

Description

Helper method for drivers which have SATA cables

Name

`ata_dev_pair` — return other device on cable

Synopsis

```
struct ata_device * ata_dev_pair (struct ata_device * adev);
```

Arguments

adev device

Description

Obtain the other device on the same cable, or if none is present NULL is returned

Name

sata_set_spd — set SATA spd according to spd limit

Synopsis

```
int sata_set_spd (struct ata_link * link);
```

Arguments

link Link to set SATA spd for

Description

Set SATA spd of *link* according to sata_spd_limit.

LOCKING

Inherited from caller.

RETURNS

0 if spd doesn't need to be changed, 1 if spd has been changed. Negative errno if SCR registers are inaccessible.

Name

`ata_timing_cycle2mode` — find xfer mode for the specified cycle duration

Synopsis

```
u8 ata_timing_cycle2mode (unsigned int xfer_shift, int cycle);
```

Arguments

xfer_shift ATA_SHIFT_* value for transfer type to examine.

cycle cycle duration in ns

Description

Return matching xfer mode for *cycle*. The returned mode is of the transfer type specified by *xfer_shift*. If *cycle* is too slow for *xfer_shift*, 0xff is returned. If *cycle* is faster than the fastest known mode, the fastest mode is returned.

LOCKING

None.

RETURNS

Matching `xfer_mode`, 0xff if no match found.

Name

`ata_do_set_mode` — Program timings and issue SET FEATURES - XFER

Synopsis

```
int ata_do_set_mode (struct ata_link * link, struct ata_device **  
r_failed_dev);
```

Arguments

link link on which timings will be programmed

r_failed_dev out parameter for failed device

Description

Standard implementation of the function used to tune and set ATA device disk transfer mode (PIO3, UDMA6, etc.). If `ata_dev_set_mode` fails, pointer to the failing device is returned in *r_failed_dev*.

LOCKING

PCI/etc. bus probe sem.

RETURNS

0 on success, negative errno otherwise

Name

`ata_wait_after_reset` — wait for link to become ready after reset

Synopsis

```
int ata_wait_after_reset (struct ata_link * link, unsigned long
deadline, int (*check_ready) (struct ata_link *link));
```

Arguments

<i>link</i>	link to be waited on
<i>deadline</i>	deadline jiffies for the operation
<i>check_ready</i>	callback to check link readiness

Description

Wait for *link* to become ready after reset.

LOCKING

EH context.

RETURNS

0 if *link* is ready before *deadline*; otherwise, -errno.

Name

sata_link_debounce — debounce SATA phy status

Synopsis

```
int sata_link_debounce (struct ata_link * link, const unsigned long *
params, unsigned long deadline);
```

Arguments

link ATA link to debounce SATA phy status for

params timing parameters { interval, duration, timeout } in msec

deadline deadline jiffies for the operation

Description

Make sure SStatus of *link* reaches stable state, determined by holding the same value where DET is not 1 for *duration* polled every *interval*, before *timeout*. Timeout constraints the beginning of the stable state. Because DET gets stuck at 1 on some controllers after hot unplugging, this functions waits until timeout then returns 0 if DET is stable at 1.

timeout is further limited by *deadline*. The sooner of the two is used.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno on failure.

Name

sata_link_resume — resume SATA link

Synopsis

```
int sata_link_resume (struct ata_link * link, const unsigned long *  
params, unsigned long deadline);
```

Arguments

link ATA link to resume SATA

params timing parameters { interval, duration, timeout } in msec

deadline deadline jiffies for the operation

Description

Resume SATA phy *link* and debounce it.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno on failure.

Name

sata_link_scr_lpm — manipulate SControl IPM and SPM fields

Synopsis

```
int sata_link_scr_lpm (struct ata_link * link, enum ata_lpm_policy
policy, bool spm_wakeup);
```

Arguments

link ATA link to manipulate SControl for

policy LPM policy to configure

spm_wakeup initiate LPM transition to active state

Description

Manipulate the IPM field of the SControl register of *link* according to *policy*. If *policy* is ATA_LPM_MAX_POWER and *spm_wakeup* is `true`, the SPM field is manipulated to wake up the link. This function also clears PHYRDY_CHG before returning.

LOCKING

EH context.

RETURNS

0 on success, -errno otherwise.

Name

`ata_std_prereset` — prepare for reset

Synopsis

```
int ata_std_prereset (struct ata_link * link, unsigned long deadline);
```

Arguments

link ATA link to be reset

deadline deadline jiffies for the operation

Description

link is about to be reset. Initialize it. Failure from prereset makes libata abort whole reset sequence and give up that port, so prereset should be best-effort. It does its best to prepare for reset sequence but if things go wrong, it should just whine, not fail.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise.

Name

sata_link_hardreset — reset link via SATA phy reset

Synopsis

```
int sata_link_hardreset (struct ata_link * link, const unsigned long
* timing, unsigned long deadline, bool * online, int (*check_ready)
(struct ata_link *));
```

Arguments

<i>link</i>	link to reset
<i>timing</i>	timing parameters { interval, duration, timeout } in msec
<i>deadline</i>	deadline jiffies for the operation
<i>online</i>	optional out parameter indicating link onlineness
<i>check_ready</i>	optional callback to check link readiness

Description

SATA phy-reset *link* using DET bits of SControl register. After hardreset, link readiness is waited upon using `ata_wait_ready` if *check_ready* is specified. LLDs are allowed to not specify *check_ready* and wait itself after this function returns. Device classification is LLD's responsibility.

**online* is set to one iff reset succeeded and *link* is online after reset.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise.

Name

sata_std_hardreset — COMRESET w/o waiting or classification

Synopsis

```
int sata_std_hardreset (struct ata_link * link, unsigned int * class,  
unsigned long deadline);
```

Arguments

<i>link</i>	link to reset
<i>class</i>	resulting class of attached device
<i>deadline</i>	deadline jiffies for the operation

Description

Standard SATA COMRESET w/o waiting or classification.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 if link offline, -EAGAIN if link online, -errno on errors.

Name

`ata_std_postreset` — standard postreset callback

Synopsis

```
void ata_std_postreset (struct ata_link * link, unsigned int * classes);
```

Arguments

link the target `ata_link`

classes classes of attached devices

Description

This function is invoked after a successful reset. Note that the device might have been reset more than once using different reset methods before `postreset` is invoked.

LOCKING

Kernel thread context (may sleep)

Name

`ata_dev_set_feature` — Issue SET FEATURES - SATA FEATURES

Synopsis

```
unsigned int ata_dev_set_feature (struct ata_device * dev, u8 enable,  
u8 feature);
```

Arguments

dev Device to which command will be sent

enable Whether to enable or disable the feature

feature The sector count represents the feature to set

Description

Issue SET FEATURES - SATA FEATURES command to device *dev* on port *ap* with sector count

LOCKING

PCI/etc. bus probe sem.

RETURNS

0 on success, AC_ERR_* mask otherwise.

Name

`ata_std_qc_defer` — Check whether a qc needs to be deferred

Synopsis

```
int ata_std_qc_defer (struct ata_queued_cmd * qc);
```

Arguments

qc ATA command in question

Description

Non-NCQ commands cannot run with any other command, NCQ or not. As upper layer only knows the queue depth, we are responsible for maintaining exclusion. This function checks whether a new command *qc* can be issued.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

`ATA_DEFER_*` if deferring is needed, 0 otherwise.

Name

`ata_sg_init` — Associate command with scatter-gather table.

Synopsis

```
void ata_sg_init (struct ata_queued_cmd * qc, struct scatterlist * sg,  
unsigned int n_elem);
```

Arguments

qc Command to be associated

sg Scatter-gather table.

n_elem Number of elements in s/g table.

Description

Initialize the data-related elements of `queued_cmd` *qc* to point to a scatter-gather table *sg*, containing *n_elem* elements.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_qc_complete` — Complete an active ATA command

Synopsis

```
void ata_qc_complete (struct ata_queued_cmd * qc);
```

Arguments

qc Command to complete

Description

Indicate to the mid and upper layers that an ATA command has completed, with either an ok or not-ok status.

Refrain from calling this function multiple times when successfully completing multiple NCQ commands. `ata_qc_complete_multiple` should be used instead, which will properly update IRQ expect state.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_qc_complete_multiple` — Complete multiple qcs successfully

Synopsis

```
int ata_qc_complete_multiple (struct ata_port * ap, u32 qc_active);
```

Arguments

ap port in question

qc_active new qc_active mask

Description

Complete in-flight commands. This functions is meant to be called from low-level driver's interrupt routine to complete requests normally. `ap->qc_active` and *qc_active* is compared and commands are completed accordingly.

Always use this function when completing multiple NCQ commands from IRQ handlers instead of calling `ata_qc_complete` multiple times to keep IRQ expect status properly in sync.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Number of completed commands on success, -errno otherwise.

Name

`sata_scr_valid` — test whether SCRs are accessible

Synopsis

```
int sata_scr_valid (struct ata_link * link);
```

Arguments

link ATA link to test SCR accessibility for

Description

Test whether SCRs are accessible for *link*.

LOCKING

None.

RETURNS

1 if SCRs are accessible, 0 otherwise.

Name

`sata_scr_read` — read SCR register of the specified port

Synopsis

```
int sata_scr_read (struct ata_link * link, int reg, u32 * val);
```

Arguments

link ATA link to read SCR for

reg SCR to read

val Place to store read value

Description

Read SCR register *reg* of *link* into **val*. This function is guaranteed to succeed if *link* is `ap->link`, the cable type of the port is SATA and the port implements `->scr_read`.

LOCKING

None if *link* is `ap->link`. Kernel thread context otherwise.

RETURNS

0 on success, negative errno on failure.

Name

sata_scr_write — write SCR register of the specified port

Synopsis

```
int sata_scr_write (struct ata_link * link, int reg, u32 val);
```

Arguments

link ATA link to write SCR for

reg SCR to write

val value to write

Description

Write *val* to SCR register *reg* of *link*. This function is guaranteed to succeed if *link* is ap->link, the cable type of the port is SATA and the port implements ->scr_read.

LOCKING

None if *link* is ap->link. Kernel thread context otherwise.

RETURNS

0 on success, negative errno on failure.

Name

`sata_scr_write_flush` — write SCR register of the specified port and flush

Synopsis

```
int sata_scr_write_flush (struct ata_link * link, int reg, u32 val);
```

Arguments

link ATA link to write SCR for

reg SCR to write

val value to write

Description

This function is identical to `sata_scr_write` except that this function performs flush after writing to the register.

LOCKING

None if *link* is ap->link. Kernel thread context otherwise.

RETURNS

0 on success, negative errno on failure.

Name

`ata_link_online` — test whether the given link is online

Synopsis

```
bool ata_link_online (struct ata_link * link);
```

Arguments

link ATA link to test

Description

Test whether *link* is online. This is identical to `ata_phys_link_online` when there's no slave link. When there's a slave link, this function should only be called on the master link and will return true if any of M/S links is online.

LOCKING

None.

RETURNS

True if the port online status is available and online.

Name

`ata_link_offline` — test whether the given link is offline

Synopsis

```
bool ata_link_offline (struct ata_link * link);
```

Arguments

link ATA link to test

Description

Test whether *link* is offline. This is identical to `ata_phys_link_offline` when there's no slave link. When there's a slave link, this function should only be called on the master link and will return true if both M/S links are offline.

LOCKING

None.

RETURNS

True if the port offline status is available and offline.

Name

`ata_host_suspend` — suspend host

Synopsis

```
int ata_host_suspend (struct ata_host * host, pm_message_t mesg);
```

Arguments

host host to suspend

mesg PM message

Description

Suspend *host*. Actual operation is performed by port suspend.

Name

`ata_host_resume` — resume host

Synopsis

```
void ata_host_resume (struct ata_host * host);
```

Arguments

host host to resume

Description

Resume *host*. Actual operation is performed by port resume.

Name

`ata_host_alloc` — allocate and init basic ATA host resources

Synopsis

```
struct ata_host * ata_host_alloc (struct device * dev, int max_ports);
```

Arguments

dev generic device this host is associated with

max_ports maximum number of ATA ports associated with this host

Description

Allocate and initialize basic ATA host resources. LLD calls this function to allocate a host, initializes it fully and attaches it using `ata_host_register`.

max_ports ports are allocated and `host->n_ports` is initialized to *max_ports*. The caller is allowed to decrease `host->n_ports` before calling `ata_host_register`. The unused ports will be automatically freed on registration.

RETURNS

Allocate ATA host on success, NULL on failure.

LOCKING

Inherited from calling layer (may sleep).

Name

`ata_host_alloc_pinfo` — alloc host and init with `port_info` array

Synopsis

```
struct ata_host * ata_host_alloc_pinfo (struct device * dev, const
struct ata_port_info *const * ppi, int n_ports);
```

Arguments

dev generic device this host is associated with

ppi array of ATA `port_info` to initialize host with

n_ports number of ATA ports attached to this host

Description

Allocate ATA host and initialize with info from *ppi*. If NULL terminated, *ppi* may contain fewer entries than *n_ports*. The last entry will be used for the remaining ports.

RETURNS

Allocate ATA host on success, NULL on failure.

LOCKING

Inherited from calling layer (may sleep).

Name

`ata_slave_link_init` — initialize slave link

Synopsis

```
int ata_slave_link_init (struct ata_port * ap);
```

Arguments

ap port to initialize slave link for

Description

Create and initialize slave link for *ap*. This enables slave link handling on the port.

In libata, a port contains links and a link contains devices. There is single host link but if a PMP is attached to it, there can be multiple fan-out links. On SATA, there's usually a single device connected to a link but PATA and SATA controllers emulating TF based interface can have two - master and slave.

However, there are a few controllers which don't fit into this abstraction too well - SATA controllers which emulate TF interface with both master and slave devices but also have separate SCR register sets for each device. These controllers need separate links for physical link handling (e.g. onlineness, link speed) but should be treated like a traditional M/S controller for everything else (e.g. command issue, softreset).

`slave_link` is libata's way of handling this class of controllers without impacting core layer too much. For anything other than physical link handling, the default host link is used for both master and slave. For physical link handling, separate *ap*->`slave_link` is used. All dirty details are implemented inside libata core layer. From LLD's POV, the only difference is that `prereset`, `hardreset` and `postreset` are called once more for the slave link, so the reset sequence looks like the following.

`prereset(M) -> prereset(S) -> hardreset(M) -> hardreset(S) -> softreset(M) -> postreset(M) -> postreset(S)`

Note that `softreset` is called only for the master. `Softreset` resets both M/S by definition, so `SRST` on master should handle both (the standard method will work just fine).

LOCKING

Should be called before host is registered.

RETURNS

0 on success, `-errno` on failure.

Name

`ata_host_start` — start and freeze ports of an ATA host

Synopsis

```
int ata_host_start (struct ata_host * host);
```

Arguments

host ATA host to start ports for

Description

Start and then freeze ports of *host*. Started status is recorded in `host->flags`, so this function can be called multiple times. Ports are guaranteed to get started only once. If `host->ops` isn't initialized yet, its set to the first non-dummy port ops.

LOCKING

Inherited from calling layer (may sleep).

RETURNS

0 if all ports are started successfully, `-errno` otherwise.

Name

`ata_host_init` — Initialize a host struct for sas (ipr, libsas)

Synopsis

```
void ata_host_init (struct ata_host * host, struct device * dev, struct  
ata_port_operations * ops);
```

Arguments

host host to initialize

dev device host is attached to

ops port_ops

Name

`ata_host_register` — register initialized ATA host

Synopsis

```
int ata_host_register (struct ata_host * host, struct scsi_host_template  
* sht);
```

Arguments

host ATA host to register

sht template for SCSI host

Description

Register initialized ATA host. *host* is allocated using `ata_host_alloc` and fully initialized by LLD. This function starts ports, registers *host* with ATA and SCSI layers and probe registered devices.

LOCKING

Inherited from calling layer (may sleep).

RETURNS

0 on success, -errno otherwise.

Name

`ata_host_activate` — start host, request IRQ and register it

Synopsis

```
int ata_host_activate (struct ata_host * host, int irq, irq_handler_t
irq_handler, unsigned long irq_flags, struct scsi_host_template * sht);
```

Arguments

<i>host</i>	target ATA host
<i>irq</i>	IRQ to request
<i>irq_handler</i>	<code>irq_handler</code> used when requesting IRQ
<i>irq_flags</i>	<code>irq_flags</code> used when requesting IRQ
<i>sht</i>	<code>scsi_host_template</code> to use when registering the host

Description

After allocating an ATA host and initializing it, most libata LLDs perform three steps to activate the host - start host, request IRQ and register it. This helper takes necessary arguments and performs the three steps in one go.

An invalid IRQ skips the IRQ registration and expects the host to have set polling mode on the port. In this case, *irq_handler* should be NULL.

LOCKING

Inherited from calling layer (may sleep).

RETURNS

0 on success, -errno otherwise.

Name

`ata_host_detach` — Detach all ports of an ATA host

Synopsis

```
void ata_host_detach (struct ata_host * host);
```

Arguments

host Host to detach

Description

Detach all ports of *host*.

LOCKING

Kernel thread context (may sleep).

Name

`ata_pci_remove_one` — PCI layer callback for device removal

Synopsis

```
void ata_pci_remove_one (struct pci_dev * pdev);
```

Arguments

pdev PCI device that was removed

Description

PCI layer indicates to libata via this hook that hot-unplug or module unload event has occurred. Detach all ports. Resource release is handled via devres.

LOCKING

Inherited from PCI layer (may sleep).

Name

`ata_platform_remove_one` — Platform layer callback for device removal

Synopsis

```
int ata_platform_remove_one (struct platform_device * pdev);
```

Arguments

pdev Platform device that was removed

Description

Platform layer indicates to libata via this hook that hot-unplug or module unload event has occurred. Detach all ports. Resource release is handled via devres.

LOCKING

Inherited from platform layer (may sleep).

Name

`ata_msleep` — ATA EH owner aware msleep

Synopsis

```
void ata_msleep (struct ata_port * ap, unsigned int msecs);
```

Arguments

ap ATA port to attribute the sleep to

msecs duration to sleep in milliseconds

Description

Sleeps *msecs*. If the current task is owner of *ap*'s EH, the ownership is released before going to sleep and reacquired after the sleep is complete. IOW, other ports sharing the *ap*->host will be allowed to own the EH while this task is sleeping.

LOCKING

Might sleep.

Name

`ata_wait_register` — wait until register value changes

Synopsis

```
u32 ata_wait_register (struct ata_port * ap, void __iomem * reg, u32
mask, u32 val, unsigned long interval, unsigned long timeout);
```

Arguments

<i>ap</i>	ATA port to wait register for, can be NULL
<i>reg</i>	IO-mapped register
<i>mask</i>	Mask to apply to read register value
<i>val</i>	Wait condition
<i>interval</i>	polling interval in milliseconds
<i>timeout</i>	timeout in milliseconds

Description

Waiting for some bits of register to change is a common operation for ATA controllers. This function reads 32bit LE IO-mapped register *reg* and tests for the following condition.

$(*reg \& \text{mask}) \neq \text{val}$

If the condition is met, it returns; otherwise, the process is repeated after *interval_msec* until timeout.

LOCKING

Kernel thread context (may sleep)

RETURNS

The final register value.

Name

`sata_lpm_ignore_phy_events` — test if PHY event should be ignored

Synopsis

```
bool sata_lpm_ignore_phy_events (struct ata_link * link);
```

Arguments

link Link receiving the event

Description

Test whether the received PHY event has to be ignored or not.

RETURNS

True if the event has to be ignored.

Chapter 5. libata Core Internals

Name

`ata_dev_phys_link` — find physical link for a device

Synopsis

```
struct ata_link * ata_dev_phys_link (struct ata_device * dev);
```

Arguments

dev ATA device to look up physical link for

Description

Look up physical link which *dev* is attached to. Note that this is different from *dev*->link only when *dev* is on slave link. For all other cases, it's the same as *dev*->link.

LOCKING

Don't care.

RETURNS

Pointer to the found physical link.

Name

`ata_force_cbl` — force cable type according to `libata.force`

Synopsis

```
void ata_force_cbl (struct ata_port * ap);
```

Arguments

ap ATA port of interest

Description

Force cable type according to `libata.force` and whine about it. The last entry which has matching port number is used, so it can be specified as part of device force parameters. For example, both “a:40c,1.00:udma4” and “1.00:40c,udma4” have the same effect.

LOCKING

EH context.

Name

`ata_force_link_limits` — force link limits according to `libata.force`

Synopsis

```
void ata_force_link_limits (struct ata_link * link);
```

Arguments

link ATA link of interest

Description

Force link flags and SATA spd limit according to `libata.force` and whine about it. When only the port part is specified (e.g. 1:), the limit applies to all links connected to both the host link and all fan-out ports connected via PMP. If the device part is specified as 0 (e.g. 1.00:), it specifies the first fan-out link not the host link. Device number 15 always points to the host link whether PMP is attached or not. If the controller has slave link, device number 16 points to it.

LOCKING

EH context.

Name

`ata_force_xfermask` — force xfermask according to `libata.force`

Synopsis

```
void ata_force_xfermask (struct ata_device * dev);
```

Arguments

dev ATA device of interest

Description

Force `xfer_mask` according to `libata.force` and whine about it. For consistency with link selection, device number 15 selects the first device connected to the host link.

LOCKING

EH context.

Name

`ata_force_horkage` — force horkage according to `libata.force`

Synopsis

```
void ata_force_horkage (struct ata_device * dev);
```

Arguments

dev ATA device of interest

Description

Force horkage according to `libata.force` and whine about it. For consistency with link selection, device number 15 selects the first device connected to the host link.

LOCKING

EH context.

Name

`ata_rwcmd_protocol` — set taskfile r/w commands and protocol

Synopsis

```
int ata_rwcmd_protocol (struct ata_taskfile * tf, struct ata_device *  
dev);
```

Arguments

tf command to examine and configure

dev device *tf* belongs to

Description

Examine the device configuration and *tf*->flags to calculate the proper read/write commands and protocol to use.

LOCKING

caller.

Name

`ata_tf_read_block` — Read block address from ATA taskfile

Synopsis

```
u64 ata_tf_read_block (const struct ata_taskfile * tf, struct ata_device  
* dev);
```

Arguments

tf ATA taskfile of interest

dev ATA device *tf* belongs to

LOCKING

None.

Read block address from *tf*. This function can handle all three address formats - LBA, LBA48 and CHS. *tf*->protocol and flags select the address format to use.

RETURNS

Block address read from *tf*.

Name

`ata_build_rw_tf` — Build ATA taskfile for given read/write request

Synopsis

```
int ata_build_rw_tf (struct ata_taskfile * tf, struct ata_device * dev,  
u64 block, u32 n_block, unsigned int tf_flags, unsigned int tag, int  
class);
```

Arguments

<i>tf</i>	Target ATA taskfile
<i>dev</i>	ATA device <i>tf</i> belongs to
<i>block</i>	Block address
<i>n_block</i>	Number of blocks
<i>tf_flags</i>	RW/FUA etc...
<i>tag</i>	tag
<i>class</i>	IO priority class

LOCKING

None.

Build ATA taskfile *tf* for read/write request described by *block*, *n_block*, *tf_flags* and *tag* on *dev*.

RETURNS

0 on success, -ERANGE if the request is too large for *dev*, -EINVAL if the request is invalid.

Name

`ata_read_native_max_address` — Read native max address

Synopsis

```
int  ata_read_native_max_address (struct ata_device * dev, u64 *
max_sectors);
```

Arguments

dev target device

max_sectors out parameter for the result native max address

Description

Perform an LBA48 or LBA28 native size query upon the device in question.

RETURNS

0 on success, -EACCES if command is aborted by the drive, -EIO on other errors.

Name

`ata_set_max_sectors` — Set max sectors

Synopsis

```
int ata_set_max_sectors (struct ata_device * dev, u64 new_sectors);
```

Arguments

dev target device

new_sectors new max sectors value to set for the device

Description

Set max sectors of *dev* to *new_sectors*.

RETURNS

0 on success, -EACCES if command is aborted or denied (due to previous non-volatile SET_MAX) by the drive, -EIO on other errors.

Name

`ata_hpa_resize` — Resize a device with an HPA set

Synopsis

```
int ata_hpa_resize (struct ata_device * dev);
```

Arguments

dev Device to resize

Description

Read the size of an LBA28 or LBA48 disk with HPA features and resize it if required to the full size of the media. The caller must check the drive has the HPA feature set enabled.

RETURNS

0 on success, -errno on failure.

Name

`ata_dump_id` — IDENTIFY DEVICE info debugging output

Synopsis

```
void ata_dump_id (const u16 * id);
```

Arguments

id IDENTIFY DEVICE page to dump

Description

Dump selected 16-bit words from the given IDENTIFY DEVICE page.

LOCKING

caller.

Name

`ata_exec_internal_sg` — execute libata internal command

Synopsis

```
unsigned ata_exec_internal_sg (struct ata_device * dev, struct
ata_taskfile * tf, const u8 * cdb, int dma_dir, struct scatterlist *
sgl, unsigned int n_elem, unsigned long timeout);
```

Arguments

<i>dev</i>	Device to which the command is sent
<i>tf</i>	Taskfile registers for the command and the result
<i>cdb</i>	CDB for packet command
<i>dma_dir</i>	Data transfer direction of the command
<i>sgl</i>	sg list for the data buffer of the command
<i>n_elem</i>	Number of sg entries
<i>timeout</i>	Timeout in msecs (0 for default)

Description

Executes libata internal command with timeout. *tf* contains command on entry and result on return. Timeout and error conditions are reported via return value. No recovery action is taken after a command times out. It's caller's duty to clean up after timeout.

LOCKING

None. Should be called with kernel context, might sleep.

RETURNS

Zero on success, `AC_ERR_*` mask on failure

Name

`ata_exec_internal` — execute libata internal command

Synopsis

```
unsigned ata_exec_internal (struct ata_device * dev, struct ata_taskfile  
* tf, const u8 * cdb, int dma_dir, void * buf, unsigned int buflen,  
unsigned long timeout);
```

Arguments

<i>dev</i>	Device to which the command is sent
<i>tf</i>	Taskfile registers for the command and the result
<i>cdb</i>	CDB for packet command
<i>dma_dir</i>	Data transfer direction of the command
<i>buf</i>	Data buffer of the command
<i>buflen</i>	Length of data buffer
<i>timeout</i>	Timeout in msecs (0 for default)

Description

Wrapper around `ata_exec_internal_sg` which takes simple buffer instead of sg list.

LOCKING

None. Should be called with kernel context, might sleep.

RETURNS

Zero on success, `AC_ERR_*` mask on failure

Name

`ata_pio_mask_no_iordy` — Return the non IORDY mask

Synopsis

```
u32 ata_pio_mask_no_iordy (const struct ata_device * adev);
```

Arguments

adev ATA device

Description

Compute the highest mode possible if we are not using iordy. Return -1 if no iordy mode is available.

Name

`ata_dev_read_id` — Read ID data from the specified device

Synopsis

```
int ata_dev_read_id (struct ata_device * dev, unsigned int * p_class,  
unsigned int flags, u16 * id);
```

Arguments

<i>dev</i>	target device
<i>p_class</i>	pointer to class of the target device (may be changed)
<i>flags</i>	ATA_READID_* flags
<i>id</i>	buffer to read IDENTIFY data into

Description

Read ID data from the specified device. `ATA_CMD_ID_ATA` is performed on ATA devices and `ATA_CMD_ID_ATAPI` on ATAPI devices. This function also issues `ATA_CMD_INIT_DEV_PARAMS` for pre-ATA4 drives.

FIXME

`ATA_CMD_ID_ATA` is optional for early drives and right now we abort if we hit that case.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise.

Name

`ata_dev_configure` — Configure the specified ATA/ATAPI device

Synopsis

```
int ata_dev_configure (struct ata_device * dev);
```

Arguments

dev Target device to configure

Description

Configure *dev* according to *dev->id*. Generic and low-level driver specific fixups are also applied.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, -errno otherwise

Name

`ata_bus_probe` — Reset and probe ATA bus

Synopsis

```
int ata_bus_probe (struct ata_port * ap);
```

Arguments

ap Bus to probe

Description

Master ATA bus probing function. Initiates a hardware-dependent bus reset, then attempts to identify any devices found on the bus.

LOCKING

PCI/etc. bus probe sem.

RETURNS

Zero on success, negative errno otherwise.

Name

`sata_print_link_status` — Print SATA link status

Synopsis

```
void sata_print_link_status (struct ata_link * link);
```

Arguments

link SATA link to printk link status about

Description

This function prints link speed and status of a SATA link.

LOCKING

None.

Name

sata_down_spd_limit — adjust SATA spd limit downward

Synopsis

```
int sata_down_spd_limit (struct ata_link * link, u32 spd_limit);
```

Arguments

link Link to adjust SATA spd limit for

spd_limit Additional limit

Description

Adjust SATA spd limit of *link* downward. Note that this function only adjusts the limit. The change must be applied using `sata_set_spd`.

If *spd_limit* is non-zero, the speed is limited to equal to or lower than *spd_limit* if such speed is supported. If *spd_limit* is slower than any supported speed, only the lowest supported speed is allowed.

LOCKING

Inherited from caller.

RETURNS

0 on success, negative errno on failure

Name

`sata_set_spd_needed` — is SATA spd configuration needed

Synopsis

```
int sata_set_spd_needed (struct ata_link * link);
```

Arguments

link Link in question

Description

Test whether the spd limit in SControl matches *link*->sata_spd_limit. This function is used to determine whether hardreset is necessary to apply SATA spd configuration.

LOCKING

Inherited from caller.

RETURNS

1 if SATA spd configuration is needed, 0 otherwise.

Name

`ata_down_xfermask_limit` — adjust dev xfer masks downward

Synopsis

```
int ata_down_xfermask_limit (struct ata_device * dev, unsigned int sel);
```

Arguments

dev Device to adjust xfer masks

sel ATA_DNXFER_* selector

Description

Adjust xfer masks of *dev* downward. Note that this function does not apply the change. Invoking `ata_set_mode` afterwards will apply the limit.

LOCKING

Inherited from caller.

RETURNS

0 on success, negative errno on failure

Name

`ata_wait_ready` — wait for link to become ready

Synopsis

```
int ata_wait_ready (struct ata_link * link, unsigned long deadline, int
(*check_ready) (struct ata_link *link));
```

Arguments

<i>link</i>	link to be waited on
<i>deadline</i>	deadline jiffies for the operation
<i>check_ready</i>	callback to check link readiness

Description

Wait for *link* to become ready. *check_ready* should return positive number if *link* is ready, 0 if it isn't, -ENODEV if link doesn't seem to be occupied, other errno for other error conditions.

Transient -ENODEV conditions are allowed for ATA_TMOUT_FF_WAIT.

LOCKING

EH context.

RETURNS

0 if *linke* is ready before *deadline*; otherwise, -errno.

Name

`ata_dev_same_device` — Determine whether new ID matches configured device

Synopsis

```
int  ata_dev_same_device (struct ata_device * dev, unsigned int
new_class, const u16 * new_id);
```

Arguments

dev device to compare against
new_class class of the new device
new_id IDENTIFY page of the new device

Description

Compare *new_class* and *new_id* against *dev* and determine whether *dev* is the device indicated by *new_class* and *new_id*.

LOCKING

None.

RETURNS

1 if *dev* matches *new_class* and *new_id*, 0 otherwise.

Name

`ata_dev_reread_id` — Re-read IDENTIFY data

Synopsis

```
int  ata_dev_reread_id (struct ata_device * dev, unsigned int
readid_flags);
```

Arguments

dev target ATA device

readid_flags read ID flags

Description

Re-read IDENTIFY page and make sure *dev* is still attached to the port.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, negative errno otherwise

Name

`ata_dev_revalidate` — Revalidate ATA device

Synopsis

```
int ata_dev_revalidate (struct ata_device * dev, unsigned int new_class,  
unsigned int readid_flags);
```

Arguments

dev device to revalidate

new_class new class code

readid_flags read ID flags

Description

Re-read IDENTIFY page, make sure *dev* is still attached to the port and reconfigure it according to the new IDENTIFY page.

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, negative errno otherwise

Name

`ata_is_40wire` — check drive side detection

Synopsis

```
int ata_is_40wire (struct ata_device * dev);
```

Arguments

dev device

Description

Perform drive side detection decoding, allowing for device vendors who can't follow the documentation.

Name

`cable_is_40wire` — 40/80/SATA decider

Synopsis

```
int cable_is_40wire (struct ata_port * ap);
```

Arguments

ap port to consider

Description

This function encapsulates the policy for speed management in one place. At the moment we don't cache the result but there is a good case for setting `ap->cbl` to the result when we are called with unknown cables (and figuring out if it impacts hotplug at all).

Return 1 if the cable appears to be 40 wire.

Name

`ata_dev_xfermask` — Compute supported xfermask of the given device

Synopsis

```
void ata_dev_xfermask (struct ata_device * dev);
```

Arguments

dev Device to compute xfermask for

Description

Compute supported xfermask of *dev* and store it in `dev->*_mask`. This function is responsible for applying all known limits including host controller limits, device blacklist, etc...

LOCKING

None.

Name

`ata_dev_set_xfermode` — Issue SET FEATURES - XFER MODE command

Synopsis

```
unsigned int ata_dev_set_xfermode (struct ata_device * dev);
```

Arguments

dev Device to which command will be sent

Description

Issue SET FEATURES - XFER MODE command to device *dev* on port *ap*.

LOCKING

PCI/etc. bus probe sem.

RETURNS

0 on success, `AC_ERR_*` mask otherwise.

Name

`ata_dev_init_params` — Issue INIT DEV PARAMS command

Synopsis

```
unsigned int ata_dev_init_params (struct ata_device * dev, u16 heads,  
u16 sectors);
```

Arguments

dev Device to which command will be sent

heads Number of heads (taskfile parameter)

sectors Number of sectors (taskfile parameter)

LOCKING

Kernel thread context (may sleep)

RETURNS

0 on success, `AC_ERR_*` mask otherwise.

Name

`ata_sg_clean` — Unmap DMA memory associated with command

Synopsis

```
void ata_sg_clean (struct ata_queued_cmd * qc);
```

Arguments

qc Command containing DMA memory to be released

Description

Unmap all mapped DMA memory associated with this command.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`atapi_check_dma` — Check whether ATAPI DMA can be supported

Synopsis

```
int atapi_check_dma (struct ata_queued_cmd * qc);
```

Arguments

qc Metadata associated with taskfile to check

Description

Allow low-level driver to filter ATA PACKET commands, returning a status indicating whether or not it is OK to use DMA for the supplied PACKET command.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

0 when ATAPI DMA can be used nonzero otherwise

Name

`ata_sg_setup` — DMA-map the scatter-gather table associated with a command.

Synopsis

```
int ata_sg_setup (struct ata_queued_cmd * qc);
```

Arguments

qc Command with scatter-gather table to be mapped.

Description

DMA-map the scatter-gather table associated with queued_cmd *qc*.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, negative on error.

Name

`swap_buf_le16` — swap halves of 16-bit words in place

Synopsis

```
void swap_buf_le16 (u16 * buf, unsigned int buf_words);
```

Arguments

buf Buffer to swap

buf_words Number of 16-bit words in buffer.

Description

Swap halves of 16-bit words if needed to convert from little-endian byte order to native cpu byte order, or vice-versa.

LOCKING

Inherited from caller.

Name

`ata_qc_new_init` — Request an available ATA command, and initialize it

Synopsis

```
struct ata_queued_cmd * ata_qc_new_init (struct ata_device * dev, int
tag);
```

Arguments

dev Device from whom we request an available command structure

tag tag

LOCKING

None.

Name

`ata_qc_free` — free unused `ata_queued_cmd`

Synopsis

```
void ata_qc_free (struct ata_queued_cmd * qc);
```

Arguments

qc Command to complete

Description

Designed to free unused `ata_queued_cmd` object in case something prevents using it.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_qc_issue` — issue taskfile to device

Synopsis

```
void ata_qc_issue (struct ata_queued_cmd * qc);
```

Arguments

qc command to issue to device

Description

Prepare an ATA command to submission to device. This includes mapping the data into a DMA-able area, filling in the S/G table, and finally writing the taskfile to hardware, starting the command.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_phys_link_online` — test whether the given link is online

Synopsis

```
bool ata_phys_link_online (struct ata_link * link);
```

Arguments

link ATA link to test

Description

Test whether *link* is online. Note that this function returns 0 if online status of *link* cannot be obtained, so `ata_link_online(link) != !ata_link_offline(link)`.

LOCKING

None.

RETURNS

True if the port online status is available and online.

Name

`ata_phys_link_offline` — test whether the given link is offline

Synopsis

```
bool ata_phys_link_offline (struct ata_link * link);
```

Arguments

link ATA link to test

Description

Test whether *link* is offline. Note that this function returns 0 if offline status of *link* cannot be obtained, so `ata_link_online(link) != !ata_link_offline(link)`.

LOCKING

None.

RETURNS

True if the port offline status is available and offline.

Name

`ata_dev_init` — Initialize an `ata_device` structure

Synopsis

```
void ata_dev_init (struct ata_device * dev);
```

Arguments

dev Device structure to initialize

Description

Initialize *dev* in preparation for probing.

LOCKING

Inherited from caller.

Name

`ata_link_init` — Initialize an `ata_link` structure

Synopsis

```
void ata_link_init (struct ata_port * ap, struct ata_link * link, int  
pmp);
```

Arguments

ap ATA port link is attached to

link Link structure to initialize

pmp Port multiplier port number

Description

Initialize *link*.

LOCKING

Kernel thread context (may sleep)

Name

`sata_link_init_spd` — Initialize `link->sata_spd_limit`

Synopsis

```
int sata_link_init_spd (struct ata_link * link);
```

Arguments

link Link to configure `sata_spd_limit` for

Description

Initialize *link*->[hw_]sata_spd_limit to the currently configured value.

LOCKING

Kernel thread context (may sleep).

RETURNS

0 on success, -errno on failure.

Name

`ata_port_alloc` — allocate and initialize basic ATA port resources

Synopsis

```
struct ata_port * ata_port_alloc (struct ata_host * host);
```

Arguments

host ATA host this allocated port belongs to

Description

Allocate and initialize basic ATA port resources.

RETURNS

Allocate ATA port on success, NULL on failure.

LOCKING

Inherited from calling layer (may sleep).

Name

`ata_finalize_port_ops` — finalize `ata_port_operations`

Synopsis

```
void ata_finalize_port_ops (struct ata_port_operations * ops);
```

Arguments

ops `ata_port_operations` to finalize

Description

An `ata_port_operations` can inherit from another ops and that ops can again inherit from another. This can go on as many times as necessary as long as there is no loop in the inheritance chain.

Ops tables are finalized when the host is started. NULL or unspecified entries are inherited from the closest ancestor which has the method and the entry is populated with it. After finalization, the ops table directly points to all the methods and `->inherits` is no longer necessary and cleared.

Using `ATA_OP_NULL`, inheriting ops can force a method to NULL.

LOCKING

None.

Name

`ata_port_detach` — Detach ATA port in preparation of device removal

Synopsis

```
void ata_port_detach (struct ata_port * ap);
```

Arguments

ap ATA port to be detached

Description

Detach all ATA devices and the associated SCSI devices of *ap*; then, remove the associated SCSI host. *ap* is guaranteed to be quiescent on return from this function.

LOCKING

Kernel thread context (may sleep).

Chapter 6. libata SCSI translation/ emulation

Name

`ata_std_bios_param` — generic bios head/sector/cylinder calculator used by sd.

Synopsis

```
int ata_std_bios_param (struct scsi_device * sdev, struct block_device
* bdev, sector_t capacity, int geom[]);
```

Arguments

sdev SCSI device for which BIOS geometry is to be determined

bdev block device associated with *sdev*

capacity capacity of SCSI device

geom[] location to which geometry will be output

Description

Generic bios head/sector/cylinder calculator used by sd. Most BIOSes nowadays expect a XXX/255/16 (CHS) mapping. Some situations may arise where the disk is not bootable if this is not used.

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero.

Name

`ata_scsi_unlock_native_capacity` — unlock native capacity

Synopsis

```
void ata_scsi_unlock_native_capacity (struct scsi_device * sdev);
```

Arguments

sdev SCSI device to adjust device capacity for

Description

This function is called if a partition on *sdev* extends beyond the end of the device. It requests EH to unlock HPA.

LOCKING

Defined by the SCSI layer. Might sleep.

Name

`ata_scsi_slave_config` — Set SCSI device attributes

Synopsis

```
int ata_scsi_slave_config (struct scsi_device * sdev);
```

Arguments

sdev SCSI device to examine

Description

This is called before we actually start reading and writing to the device, to configure certain SCSI mid-layer behaviors.

LOCKING

Defined by SCSI layer. We don't really care.

Name

`ata_scsi_slave_destroy` — SCSI device is about to be destroyed

Synopsis

```
void ata_scsi_slave_destroy (struct scsi_device * sdev);
```

Arguments

sdev SCSI device to be destroyed

Description

sdev is about to be destroyed for hot/warm unplugging. If this unplugging was initiated by libata as indicated by `NULL dev->sdev`, this function doesn't have to do anything. Otherwise, SCSI layer initiated warm-unplug is in progress. Clear `dev->sdev`, schedule the device for ATA detach and invoke EH.

LOCKING

Defined by SCSI layer. We don't really care.

Name

`__ata_change_queue_depth` — helper for `ata_scsi_change_queue_depth`

Synopsis

```
int __ata_change_queue_depth (struct ata_port * ap, struct scsi_device  
* sdev, int queue_depth);
```

Arguments

<i>ap</i>	ATA port to which the device change the queue depth
<i>sdev</i>	SCSI device to configure queue depth for
<i>queue_depth</i>	new queue depth

Description

libsas and libata have different approaches for associating a `sdev` to its `ata_port`.

Name

`ata_scsi_change_queue_depth` — SCSI callback for queue depth config

Synopsis

```
int  ata_scsi_change_queue_depth (struct scsi_device * sdev, int
queue_depth);
```

Arguments

sdev SCSI device to configure queue depth for

queue_depth new queue depth

Description

This is libata standard `hostt->change_queue_depth` callback. SCSI will call into this callback when user tries to set queue depth via `sysfs`.

LOCKING

SCSI layer (we don't care)

RETURNS

Newly configured queue depth.

Name

`ata_scsi_queuecmd` — Issue SCSI cdb to libata-managed device

Synopsis

```
int ata_scsi_queuecmd (struct Scsi_Host * shost, struct scsi_cmnd *  
cmd);
```

Arguments

shost SCSI host of command to be sent

cmd SCSI command to be sent

Description

In some cases, this function translates SCSI commands into ATA taskfiles, and queues the taskfiles to be sent to hardware. In other cases, this function simulates a SCSI device by evaluating and responding to certain SCSI commands. This creates the overall effect of ATA and ATAPI devices appearing as SCSI devices.

LOCKING

ATA host lock

RETURNS

Return value from `__ata_scsi_queuecmd` if *cmd* can be queued, 0 otherwise.

Name

`ata_scsi_simulate` — simulate SCSI command on ATA device

Synopsis

```
void ata_scsi_simulate (struct ata_device * dev, struct scsi_cmnd *  
cmd);
```

Arguments

dev the target device

cmd SCSI command being sent to device.

Description

Interprets and directly executes a select list of SCSI commands that can be handled internally.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_sas_port_alloc` — Allocate port for a SAS attached SATA device

Synopsis

```
struct ata_port * ata_sas_port_alloc (struct ata_host * host, struct
ata_port_info * port_info, struct Scsi_Host * shost);
```

Arguments

host ATA host container for all SAS ports

port_info Information from low-level host driver

shost SCSI host that the scsi device is attached to

LOCKING

PCI/etc. bus probe sem.

RETURNS

`ata_port` pointer on success / NULL on failure.

Name

`ata_sas_port_start` — Set port up for dma.

Synopsis

```
int ata_sas_port_start (struct ata_port * ap);
```

Arguments

ap Port to initialize

Description

Called just after data structures for each port are initialized.

May be used as the `port_start` entry in `ata_port_operations`.

LOCKING

Inherited from caller.

Name

`ata_sas_port_stop` — Undo `ata_sas_port_start`

Synopsis

```
void ata_sas_port_stop (struct ata_port * ap);
```

Arguments

ap Port to shut down

Description

May be used as the `port_stop` entry in `ata_port_operations`.

LOCKING

Inherited from caller.

Name

`ata_sas_async_probe` — simply schedule probing and return

Synopsis

```
void ata_sas_async_probe (struct ata_port * ap);
```

Arguments

ap Port to probe

Description

For batch scheduling of probe for sas attached ata devices, assumes the port has already been through `ata_sas_port_init`

Name

`ata_sas_port_init` — Initialize a SATA device

Synopsis

```
int ata_sas_port_init (struct ata_port * ap);
```

Arguments

ap SATA port to initialize

LOCKING

PCI/etc. bus probe sem.

RETURNS

Zero on success, non-zero on error.

Name

`ata_sas_port_destroy` — Destroy a SATA port allocated by `ata_sas_port_alloc`

Synopsis

```
void ata_sas_port_destroy (struct ata_port * ap);
```

Arguments

ap SATA port to destroy

Name

`ata_sas_slave_configure` — Default slave_config routine for libata devices

Synopsis

```
int ata_sas_slave_configure (struct scsi_device * sdev, struct ata_port  
* ap);
```

Arguments

sdev SCSI device to configure

ap ATA port to which SCSI device is attached

RETURNS

Zero.

Name

`ata_sas_queuecmd` — Issue SCSI cdb to libata-managed device

Synopsis

```
int ata_sas_queuecmd (struct scsi_cmnd * cmd, struct ata_port * ap);
```

Arguments

cmd SCSI command to be sent

ap ATA port to which the command is being sent

RETURNS

Return value from `__ata_scsi_queuecmd` if *cmd* can be queued, 0 otherwise.

Name

`ata_get_identity` — Handler for `HDIO_GET_IDENTITY` ioctl

Synopsis

```
int ata_get_identity (struct ata_port * ap, struct scsi_device * sdev,  
void __user * arg);
```

Arguments

ap target port

sdev SCSI device to get identify data for

arg User buffer area for identify data

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero on success, negative `errno` on error.

Name

`ata_cmd_ioctl` — Handler for HDIO_DRIVE_CMD ioctl

Synopsis

```
int ata_cmd_ioctl (struct scsi_device * scsidev, void __user * arg);
```

Arguments

scsidev Device to which we are issuing command

arg User provided data for issuing command

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero on success, negative errno on error.

Name

`ata_task_ioctl` — Handler for HDIO_DRIVE_TASK ioctl

Synopsis

```
int ata_task_ioctl (struct scsi_device * scsidev, void __user * arg);
```

Arguments

scsidev Device to which we are issuing command

arg User provided data for issuing command

LOCKING

Defined by the SCSI layer. We don't really care.

RETURNS

Zero on success, negative errno on error.

Name

`ata_scsi_qc_new` — acquire new `ata_queued_cmd` reference

Synopsis

```
struct ata_queued_cmd * ata_scsi_qc_new (struct ata_device * dev, struct
scsi_cmnd * cmd);
```

Arguments

dev ATA device to which the new command is attached

cmd SCSI command that originated this ATA command

Description

Obtain a reference to an unused `ata_queued_cmd` structure, which is the basic libata structure representing a single ATA command sent to the hardware.

If a command was available, fill in the SCSI-specific portions of the structure with information on the current command.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Command allocated, or NULL if none available.

Name

`ata_dump_status` — user friendly display of error info

Synopsis

```
void ata_dump_status (unsigned id, struct ata_taskfile * tf);
```

Arguments

id id of the port in question

tf ptr to filled out taskfile

Description

Decode and dump the ATA error/status registers for the user so that they have some idea what really happened at the non make-believe layer.

LOCKING

inherited from caller

Name

`ata_to_sense_error` — convert ATA error to SCSI error

Synopsis

```
void ata_to_sense_error (unsigned id, u8 drv_stat, u8 drv_err, u8 * sk,  
u8 * asc, u8 * ascq, int verbose);
```

Arguments

<i>id</i>	ATA device number
<i>drv_stat</i>	value contained in ATA status register
<i>drv_err</i>	value contained in ATA error register
<i>sk</i>	the sense key we'll fill out
<i>asc</i>	the additional sense code we'll fill out
<i>ascq</i>	the additional sense code qualifier we'll fill out
<i>verbose</i>	be verbose

Description

Converts an ATA error into a SCSI error. Fill out pointers to SK, ASC, and ASCQ bytes for later use in fixed or descriptor format sense blocks.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_gen_ata_sense` — generate a SCSI fixed sense block

Synopsis

```
void ata_gen_ata_sense (struct ata_queued_cmd * qc);
```

Arguments

qc Command that we are erroring out

Description

Generate sense block for a failed ATA command *qc*. Descriptor format is used to accommodate LBA48 block address.

LOCKING

None.

Name

`atapi_drain_needed` — Check whether data transfer may overflow

Synopsis

```
int atapi_drain_needed (struct request * rq);
```

Arguments

rq request to be checked

Description

ATAPI commands which transfer variable length data to host might overflow due to application error or hardware bug. This function checks whether overflow should be drained and ignored for *request*.

LOCKING

None.

RETURNS

1 if ; otherwise, 0.

Name

`ata_scsi_start_stop_xlat` — Translate SCSI START STOP UNIT command

Synopsis

```
unsigned int ata_scsi_start_stop_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc Storage for translated ATA taskfile

Description

Sets up an ATA taskfile to issue STANDBY (to stop) or READ VERIFY (to start). Perhaps these commands should be preceded by CHECK POWER MODE to see what power mode the device is already in. [See SAT revision 5 at www.t10.org]

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on error.

Name

`ata_scsi_flush_xlat` — Translate SCSI SYNCHRONIZE CACHE command

Synopsis

```
unsigned int ata_scsi_flush_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc Storage for translated ATA taskfile

Description

Sets up an ATA taskfile to issue FLUSH CACHE or FLUSH CACHE EXT.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on error.

Name

`scsi_6_lba_len` — Get LBA and transfer length

Synopsis

```
void scsi_6_lba_len (const u8 * cdb, u64 * plba, u32 * plen);
```

Arguments

cdb SCSI command to translate

plba the LBA

plen the transfer length

Description

Calculate LBA and transfer length for 6-byte commands.

Name

`scsi_10_lba_len` — Get LBA and transfer length

Synopsis

```
void scsi_10_lba_len (const u8 * cdb, u64 * plba, u32 * plen);
```

Arguments

cdb SCSI command to translate

plba the LBA

plen the transfer length

Description

Calculate LBA and transfer length for 10-byte commands.

Name

`scsi_16_lba_len` — Get LBA and transfer length

Synopsis

```
void scsi_16_lba_len (const u8 * cdb, u64 * plba, u32 * plen);
```

Arguments

cdb SCSI command to translate

plba the LBA

plen the transfer length

Description

Calculate LBA and transfer length for 16-byte commands.

Name

`ata_scsi_verify_xlat` — Translate SCSI VERIFY command into an ATA one

Synopsis

```
unsigned int ata_scsi_verify_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc Storage for translated ATA taskfile

Description

Converts SCSI VERIFY command to an ATA READ VERIFY command.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on error.

Name

`ata_scsi_rw_xlat` — Translate SCSI r/w command into an ATA one

Synopsis

```
unsigned int ata_scsi_rw_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc Storage for translated ATA taskfile

Description

Converts any of six SCSI read/write commands into the ATA counterpart, including starting sector (LBA), sector count, and taking into account the device's LBA48 support.

Commands `READ_6`, `READ_10`, `READ_16`, `WRITE_6`, `WRITE_10`, and `WRITE_16` are currently supported.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Zero on success, non-zero on error.

Name

`ata_scsi_translate` — Translate then issue SCSI command to ATA device

Synopsis

```
int ata_scsi_translate (struct ata_device * dev, struct scsi_cmnd * cmd,  
ata_xlat_func_t xlat_func);
```

Arguments

dev ATA device to which the command is addressed

cmd SCSI command to execute

xlat_func Actor which translates *cmd* to an ATA taskfile

Description

Our `->queuecommand` function has decided that the SCSI command issued can be directly translated into an ATA command, rather than handled internally.

This function sets up an `ata_queued_cmd` structure for the SCSI command, and sends that `ata_queued_cmd` to the hardware.

The `xlat_func` argument (actor) returns 0 if ready to execute ATA command, else 1 to finish translation. If 1 is returned then `cmd->result` (and possibly `cmd->sense_buffer`) are assumed to be set reflecting an error condition or clean (early) termination.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

0 on success, `SCSI_ML_QUEUE_DEVICE_BUSY` if the command needs to be deferred.

Name

`ata_scsi_rbuf_get` — Map response buffer.

Synopsis

```
void * ata_scsi_rbuf_get (struct scsi_cmnd * cmd, bool copy_in, unsigned  
long * flags);
```

Arguments

cmd SCSI command containing buffer to be mapped.

copy_in copy in from user buffer

flags unsigned long variable to store irq enable status

Description

Prepare buffer for simulated SCSI commands.

LOCKING

`spin_lock_irqsave(ata_scsi_rbuf_lock)` on success

RETURNS

Pointer to response buffer.

Name

`ata_scsi_rbuf_put` — Unmap response buffer.

Synopsis

```
void ata_scsi_rbuf_put (struct scsi_cmnd * cmd, bool copy_out, unsigned  
long * flags);
```

Arguments

cmd SCSI command containing buffer to be unmapped.

copy_out copy out result

flags *flags* passed to `ata_scsi_rbuf_get`

Description

Returns rbuf buffer. The result is copied to *cmd*'s buffer if *copy_back* is true.

LOCKING

Unlocks `ata_scsi_rbuf_lock`.

Name

`ata_scsi_rbuf_fill` — wrapper for SCSI command simulators

Synopsis

```
void ata_scsi_rbuf_fill (struct ata_scsi_args * args, unsigned int  
(*actor) (struct ata_scsi_args *args, u8 *rbuf));
```

Arguments

args device IDENTIFY data / SCSI command of interest.

actor Callback hook for desired SCSI command simulator

Description

Takes care of the hard work of simulating a SCSI command... Mapping the response buffer, calling the command's handler, and handling the handler's return value. This return value indicates whether the handler wishes the SCSI command to be completed successfully (0), or not (in which case `cmd->result` and sense buffer are assumed to be set).

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsiop_inq_std` — Simulate INQUIRY command

Synopsis

```
unsigned int ata_scsiop_inq_std (struct ata_scsi_args * args, u8 * rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Returns standard device identification data associated with non-VPD INQUIRY command output.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsiop_inq_00` — Simulate INQUIRY VPD page 0, list of pages

Synopsis

```
unsigned int ata_scsiop_inq_00 (struct ata_scsi_args * args, u8 * rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Returns list of inquiry VPD pages available.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsiop_inq_80` — Simulate INQUIRY VPD page 80, device serial number

Synopsis

```
unsigned int ata_scsiop_inq_80 (struct ata_scsi_args * args, u8 * rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Returns ATA device serial number.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsiop_inq_83` — Simulate INQUIRY VPD page 83, device identity

Synopsis

```
unsigned int ata_scsiop_inq_83 (struct ata_scsi_args * args, u8 * rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Yields two logical unit device identification designators

- vendor specific ASCII containing the ATA serial number - SAT defined “t10 vendor id based” containing ASCII vendor name (“ATA ”), model and serial numbers.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsiop_inq_89` — Simulate INQUIRY VPD page 89, ATA info

Synopsis

```
unsigned int ata_scsiop_inq_89 (struct ata_scsi_args * args, u8 * rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Yields SAT-specified ATA VPD page.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsiop_noop` — Command handler that simply returns success.

Synopsis

```
unsigned int ata_scsiop_noop (struct ata_scsi_args * args, u8 * rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

No operation. Simply returns success to caller, to indicate that the caller should successfully complete this SCSI command.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`modecpy` — Prepare response for MODE SENSE

Synopsis

```
void modecpy (u8 * dest, const u8 * src, int n, bool changeable);
```

Arguments

<i>dest</i>	output buffer
<i>src</i>	data being copied
<i>n</i>	length of mode page
<i>changeable</i>	whether changeable parameters are requested

Description

Generate a generic MODE SENSE page for either current or changeable parameters.

LOCKING

None.

Name

`ata_msense_caching` — Simulate MODE SENSE caching info page

Synopsis

```
unsigned int ata_msense_caching (u16 * id, u8 * buf, bool changeable);
```

Arguments

id device IDENTIFY data

buf output buffer

changeable whether changeable parameters are requested

Description

Generate a caching info page, which conditionally indicates write caching to the SCSI layer, depending on device capabilities.

LOCKING

None.

Name

`ata_msense_control` — Simulate MODE SENSE control mode page

Synopsis

```
unsigned int ata_msense_control (struct ata_device * dev, u8 * buf,  
bool changeable);
```

Arguments

dev ATA device of interest

buf output buffer

changeable whether changeable parameters are requested

Description

Generate a generic MODE SENSE control mode page.

LOCKING

None.

Name

`ata_msense_rw_recovery` — Simulate MODE SENSE r/w error recovery page

Synopsis

```
unsigned int ata_msense_rw_recovery (u8 * buf, bool changeable);
```

Arguments

buf output buffer

changeable whether changeable parameters are requested

Description

Generate a generic MODE SENSE r/w error recovery page.

LOCKING

None.

Name

`ata_scsiop_mode_sense` — Simulate MODE SENSE 6, 10 commands

Synopsis

```
unsigned int ata_scsiop_mode_sense (struct ata_scsi_args * args, u8 *  
rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Simulate MODE SENSE commands. Assume this is invoked for direct access devices (e.g. disks) only. There should be no block descriptor for other device types.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsiop_read_cap` — Simulate READ CAPACITY[16] commands

Synopsis

```
unsigned int ata_scsiop_read_cap (struct ata_scsi_args * args, u8 *  
rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Simulate READ CAPACITY commands.

LOCKING

None.

Name

`ata_scsiop_report_luns` — Simulate REPORT LUNS command

Synopsis

```
unsigned int ata_scsiop_report_luns (struct ata_scsi_args * args, u8  
* rbuf);
```

Arguments

args device IDENTIFY data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Simulate REPORT LUNS command.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_pi_xlat` — Initialize PACKET taskfile

Synopsis

```
unsigned int ata_pi_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc command structure to be initialized

LOCKING

`spin_lock_irqsave`(host lock)

RETURNS

Zero on success, non-zero on failure.

Name

`ata_scsi_find_dev` — lookup `ata_device` from `scsi_cmnd`

Synopsis

```
struct ata_device * ata_scsi_find_dev (struct ata_port * ap, const
struct scsi_device * scsidev);
```

Arguments

ap ATA port to which the device is attached

scsidev SCSI device from which we derive the ATA device

Description

Given various information provided in struct `scsi_cmnd`, map that onto an ATA bus, and using that mapping determine which `ata_device` is associated with the SCSI command to be sent.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

Associated ATA device, or `NULL` if not found.

Name

`ata_scsi_pass_thru` — convert ATA pass-thru CDB to taskfile

Synopsis

```
unsigned int ata_scsi_pass_thru (struct ata_queued_cmd * qc);
```

Arguments

qc command structure to be initialized

Description

Handles either 12 or 16-byte versions of the CDB.

RETURNS

Zero on success, non-zero on failure.

Name

`ata_format_dsm_trim_descr` — SATL Write Same to DSM Trim

Synopsis

```
size_t ata_format_dsm_trim_descr (struct scsi_cmnd * cmd, u32 trmax,  
u64 sector, u32 count);
```

Arguments

cmd SCSI command being translated

trmax Maximum number of entries that will fit in sector_size bytes.

sector Starting sector

count Total Range of request in logical sectors

Description

Rewrite the WRITE SAME descriptor to be a DSM TRIM little-endian formatted descriptor.

63

48 Range Length

47

0 LBA

Range Length of 0 is ignored. LBA's should be sorted order and not overlap.

NOTE

this is the same format as ADD LBA(S) TO NV CACHE PINNED SET

Return

Number of bytes copied into sglist.

Name

`ata_format_sct_write_same` — SATL Write Same to ATA SCT Write Same

Synopsis

```
size_t ata_format_sct_write_same (struct scsi_cmnd * cmd, u64 lba, u64
num);
```

Arguments

cmd SCSI command being translated

lba Starting sector

num Number of sectors to be zero'd.

Description

Rewrite the WRITE SAME payload to be an SCT Write Same formatted descriptor.

NOTE

Writes a pattern (0's) in the foreground.

Return

Number of bytes copied into sglist.

Name

`ata_scsi_write_same_xlat` — SATL Write Same to ATA SCT Write Same

Synopsis

```
unsigned int ata_scsi_write_same_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc Command to be translated

Description

Translate a SCSI WRITE SAME command to be either a DSM TRIM command or an SCT Write Same command. Based on WRITE SAME has the UNMAP flag When set translate to DSM TRIM When clear translate to SCT Write Same

Name

`ata_scsiop_maint_in` — Simulate a subset of MAINTENANCE_IN

Synopsis

```
unsigned int ata_scsiop_maint_in (struct ata_scsi_args * args, u8 *  
rbuf);
```

Arguments

args device MAINTENANCE_IN data / SCSI command of interest.

rbuf Response buffer, to which simulated SCSI cmd output is sent.

Description

Yields a subset to satisfy `scsi_report_opcode`

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsi_report_zones_complete` — convert ATA output

Synopsis

```
void ata_scsi_report_zones_complete (struct ata_queued_cmd * qc);
```

Arguments

qc command structure returning the data

Description

Convert T-13 little-endian field representation into T-10 big-endian field representation. What a mess.

Name

`ata_mselect_caching` — Simulate MODE SELECT for caching info page

Synopsis

```
int ata_mselect_caching (struct ata_queued_cmd * qc, const u8 * buf,  
int len, u16 * fp);
```

Arguments

qc Storage for translated ATA taskfile

buf input buffer

len number of valid bytes in the input buffer

fp out parameter for the failed field on error

Description

Prepare a taskfile to modify caching information for the device.

LOCKING

None.

Name

`ata_mselect_control` — Simulate MODE SELECT for control page

Synopsis

```
int ata_mselect_control (struct ata_queued_cmd * qc, const u8 * buf,  
int len, u16 * fp);
```

Arguments

qc Storage for translated ATA taskfile

buf input buffer

len number of valid bytes in the input buffer

fp out parameter for the failed field on error

Description

Prepare a taskfile to modify caching information for the device.

LOCKING

None.

Name

`ata_scsi_mode_select_xlat` — Simulate MODE SELECT 6, 10 commands

Synopsis

```
unsigned int ata_scsi_mode_select_xlat (struct ata_queued_cmd * qc);
```

Arguments

qc Storage for translated ATA taskfile

Description

Converts a MODE SELECT command to an ATA SET FEATURES taskfile. Assume this is invoked for direct access devices (e.g. disks) only. There should be no block descriptor for other device types.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_get_xlat_func` — check if SCSI to ATA translation is possible

Synopsis

```
ata_xlat_func_t ata_get_xlat_func (struct ata_device * dev, u8 cmd);
```

Arguments

dev ATA device

cmd SCSI command opcode to consider

Description

Look up the SCSI command given, and determine whether the SCSI command is to be translated or simulated.

RETURNS

Pointer to translation function if possible, NULL if not.

Name

`ata_scsi_dump_cdb` — dump SCSI command contents to `dmesg`

Synopsis

```
void ata_scsi_dump_cdb (struct ata_port * ap, struct scsi_cmnd * cmd);
```

Arguments

ap ATA port to which the command was being sent

cmd SCSI command to dump

Description

Prints the contents of a SCSI command via `printk`.

Name

`ata_scsi_offline_dev` — offline attached SCSI device

Synopsis

```
int ata_scsi_offline_dev (struct ata_device * dev);
```

Arguments

dev ATA device to offline attached SCSI device for

Description

This function is called from `ata_eh_hotplug` and responsible for taking the SCSI device attached to *dev* offline. This function is called with host lock which protects `dev->sdev` against clearing.

LOCKING

`spin_lock_irqsave(host lock)`

RETURNS

1 if attached SCSI device exists, 0 otherwise.

Name

`ata_scsi_remove_dev` — remove attached SCSI device

Synopsis

```
void ata_scsi_remove_dev (struct ata_device * dev);
```

Arguments

dev ATA device to remove attached SCSI device for

Description

This function is called from `ata_eh_scsi_hotplug` and responsible for removing the SCSI device attached to *dev*.

LOCKING

Kernel thread context (may sleep).

Name

`ata_scsi_media_change_notify` — send media change event

Synopsis

```
void ata_scsi_media_change_notify (struct ata_device * dev);
```

Arguments

dev Pointer to the disk device with media change event

Description

Tell the block layer to send a media change notification event.

LOCKING

`spin_lock_irqsave(host lock)`

Name

`ata_scsi_hotplug` — SCSI part of hotplug

Synopsis

```
void ata_scsi_hotplug (struct work_struct * work);
```

Arguments

work Pointer to ATA port to perform SCSI hotplug on

Description

Perform SCSI part of hotplug. It's executed from a separate workqueue after EH completes. This is necessary because SCSI hot plugging requires working EH and hot unplugging is synchronized with hot plugging with a mutex.

LOCKING

Kernel thread context (may sleep).

Name

`ata_scsi_user_scan` — indication for user-initiated bus scan

Synopsis

```
int ata_scsi_user_scan (struct Scsi_Host * shost, unsigned int channel,  
unsigned int id, u64 lun);
```

Arguments

shost SCSI host to scan

channel Channel to scan

id ID to scan

lun LUN to scan

Description

This function is called when user explicitly requests bus scan. Set probe pending flag and invoke EH.

LOCKING

SCSI layer (we don't care)

RETURNS

Zero.

Name

`ata_scsi_dev_rescan` — initiate `scsi_rescan_device`

Synopsis

```
void ata_scsi_dev_rescan (struct work_struct * work);
```

Arguments

work Pointer to ATA port to perform `scsi_rescan_device`

Description

After ATA pass thru (SAT) commands are executed successfully, libata need to propagate the changes to SCSI layer.

LOCKING

Kernel thread context (may sleep).

Chapter 7. ATA errors and exceptions

This chapter tries to identify what error/exception conditions exist for ATA/ATAPI devices and describe how they should be handled in implementation-neutral way.

The term 'error' is used to describe conditions where either an explicit error condition is reported from device or a command has timed out.

The term 'exception' is either used to describe exceptional conditions which are not errors (say, power or hotplug events), or to describe both errors and non-error exceptional conditions. Where explicit distinction between error and exception is necessary, the term 'non-error exception' is used.

Exception categories

Exceptions are described primarily with respect to legacy taskfile + bus master IDE interface. If a controller provides other better mechanism for error reporting, mapping those into categories described below shouldn't be difficult.

In the following sections, two recovery actions - reset and reconfiguring transport - are mentioned. These are described further in the section called "EH recovery actions".

HSM violation

This error is indicated when STATUS value doesn't match HSM requirement during issuing or execution any ATA/ATAPI command.

Examples

- ATA_STATUS doesn't contain !BSY && DRDY && !DRQ while trying to issue a command.
- !BSY && !DRQ during PIO data transfer.
- DRQ on command completion.
- !BSY && ERR after CDB transfer starts but before the last byte of CDB is transferred. ATA/ATAPI standard states that "The device shall not terminate the PACKET command with an error before the last byte of the command packet has been written" in the error outputs description of PACKET command and the state diagram doesn't include such transitions.

In these cases, HSM is violated and not much information regarding the error can be acquired from STATUS or ERROR register. IOW, this error can be anything - driver bug, faulty device, controller and/or cable.

As HSM is violated, reset is necessary to restore known state. Reconfiguring transport for lower speed might be helpful too as transmission errors sometimes cause this kind of errors.

ATA/ATAPI device error (non-NCQ / non-CHECK CONDITION)

These are errors detected and reported by ATA/ATAPI devices indicating device problems. For this type of errors, STATUS and ERROR register values are valid and describe error condition. Note that some of ATA bus errors are detected by ATA/ATAPI devices and reported using the same mechanism as device errors. Those cases are described later in this section.

For ATA commands, this type of errors are indicated by !BSY && ERR during command execution and on completion.

For ATAPI commands,

- !BSY && ERR && ABRT right after issuing PACKET indicates that PACKET command is not supported and falls in this category.
- !BSY && ERR(==CHK) && !ABRT after the last byte of CDB is transferred indicates CHECK CONDITION and doesn't fall in this category.
- !BSY && ERR(==CHK) && ABRT after the last byte of CDB is transferred *probably* indicates CHECK CONDITION and doesn't fall in this category.

Of errors detected as above, the followings are not ATA/ATAPI device errors but ATA bus errors and should be handled according to the section called “ATA bus error”.

CRC error during data transfer	This is indicated by ICRC bit in the ERROR register and means that corruption occurred during data transfer. Up to ATA/ATAPI-7, the standard specifies that this bit is only applicable to UDMA transfers but ATA/ATAPI-8 draft revision 1f says that the bit may be applicable to multiword DMA and PIO.
--------------------------------	---

ABRT error during data transfer or on completion	Up to ATA/ATAPI-7, the standard specifies that ABRT could be set on ICRC errors and on cases where a device is not able to complete a command. Combined with the fact that MWDMA and PIO transfer errors aren't allowed to use ICRC bit up to ATA/ATAPI-7, it seems to imply that ABRT bit alone could indicate transfer errors.
--	--

However, ATA/ATAPI-8 draft revision 1f removes the part that ICRC errors can turn on ABRT. So, this is kind of gray area. Some heuristics are needed here.

ATA/ATAPI device errors can be further categorized as follows.

Media errors	This is indicated by UNC bit in the ERROR register. ATA devices reports UNC error only after certain number of retries cannot recover the data, so there's nothing much else to do other than notifying upper layer.
--------------	--

READ and WRITE commands report CHS or LBA of the first failed sector but ATA/ATAPI standard specifies that the amount of transferred data on error completion is indeterminate, so we cannot assume that sectors preceding the failed sector have been transferred and thus cannot complete those sectors successfully as SCSI does.

Media changed / media change requested error	<<TODO: fill here>>
--	---------------------

Address error	This is indicated by IDNF bit in the ERROR register. Report to upper layer.
---------------	---

Other errors	This can be invalid command or parameter indicated by ABRT ERROR bit or some other error condition. Note that ABRT bit can indicate a lot of things including ICRC and Address errors. Heuristics needed.
--------------	---

Depending on commands, not all STATUS/ERROR bits are applicable. These non-applicable bits are marked with "na" in the output descriptions but up to ATA/ATAPI-7 no definition of "na" can be found. However, ATA/ATAPI-8 draft revision 1f describes "N/A" as follows.

3.2.3.3a N/A	A keyword that indicates a field has no defined value in this standard and should not be checked by the host or device. N/A fields should be cleared to zero.
--------------	---

So, it seems reasonable to assume that "na" bits are cleared to zero by devices and thus need no explicit masking.

ATAPI device CHECK CONDITION

ATAPI device CHECK CONDITION error is indicated by set CHK bit (ERR bit) in the STATUS register after the last byte of CDB is transferred for a PACKET command. For this kind of errors, sense data should be acquired to gather information regarding the errors. REQUEST SENSE packet command should be used to acquire sense data.

Once sense data is acquired, this type of errors can be handled similarly to other SCSI errors. Note that sense data may indicate ATA bus error (e.g. Sense Key 04h HARDWARE ERROR && ASC/ASCQ 47h/00h SCSI PARITY ERROR). In such cases, the error should be considered as an ATA bus error and handled according to the section called "ATA bus error".

ATA device error (NCQ)

NCQ command error is indicated by cleared BSY and set ERR bit during NCQ command phase (one or more NCQ commands outstanding). Although STATUS and ERROR registers will contain valid values describing the error, READ LOG EXT is required to clear the error condition, determine which command has failed and acquire more information.

READ LOG EXT Log Page 10h reports which tag has failed and taskfile register values describing the error. With this information the failed command can be handled as a normal ATA command error as in the section called "ATA/ATAPI device error (non-NCQ / non-CHECK CONDITION)" and all other in-flight commands must be retried. Note that this retry should not be counted - it's likely that commands retried this way would have completed normally if it were not for the failed command.

Note that ATA bus errors can be reported as ATA device NCQ errors. This should be handled as described in the section called "ATA bus error".

If READ LOG EXT Log Page 10h fails or reports NQ, we're thoroughly screwed. This condition should be treated according to the section called "HSM violation".

ATA bus error

ATA bus error means that data corruption occurred during transmission over ATA bus (SATA or PATA). This type of errors can be indicated by

- ICRC or ABRT error as described in the section called "ATA/ATAPI device error (non-NCQ / non-CHECK CONDITION)".
- Controller-specific error completion with error information indicating transmission error.
- On some controllers, command timeout. In this case, there may be a mechanism to determine that the timeout is due to transmission error.
- Unknown/random errors, timeouts and all sorts of weirdities.

As described above, transmission errors can cause wide variety of symptoms ranging from device ICRC error to random device lockup, and, for many cases, there is no way to tell if an error condition is due to transmission error or not; therefore, it's necessary to employ some kind of heuristic when dealing with errors and timeouts. For example, encountering repetitive ABRT errors for known supported command is likely to indicate ATA bus error.

Once it's determined that ATA bus errors have possibly occurred, lowering ATA bus transmission speed is one of actions which may alleviate the problem. See the section called “Reconfigure transport” for more information.

PCI bus error

Data corruption or other failures during transmission over PCI (or other system bus). For standard BMDMA, this is indicated by Error bit in the BMDMA Status register. This type of errors must be logged as it indicates something is very wrong with the system. Resetting host controller is recommended.

Late completion

This occurs when timeout occurs and the timeout handler finds out that the timed out command has completed successfully or with error. This is usually caused by lost interrupts. This type of errors must be logged. Resetting host controller is recommended.

Unknown error (timeout)

This is when timeout occurs and the command is still processing or the host and device are in unknown state. When this occurs, HSM could be in any valid or invalid state. To bring the device to known state and make it forget about the timed out command, resetting is necessary. The timed out command may be retried.

Timeouts can also be caused by transmission errors. Refer to the section called “ATA bus error” for more details.

Hotplug and power management exceptions

<<TODO: fill here>>

EH recovery actions

This section discusses several important recovery actions.

Clearing error condition

Many controllers require its error registers to be cleared by error handler. Different controllers may have different requirements.

For SATA, it's strongly recommended to clear at least SError register during error handling.

Reset

During EH, resetting is necessary in the following cases.

- HSM is in unknown or invalid state

- HBA is in unknown or invalid state
- EH needs to make HBA/device forget about in-flight commands
- HBA/device behaves weirdly

Resetting during EH might be a good idea regardless of error condition to improve EH robustness. Whether to reset both or either one of HBA and device depends on situation but the following scheme is recommended.

- When it's known that HBA is in ready state but ATA/ATAPI device is in unknown state, reset only device.
- If HBA is in unknown state, reset both HBA and device.

HBA resetting is implementation specific. For a controller complying to taskfile/BMDMA PCI IDE, stopping active DMA transaction may be sufficient iff BMDMA state is the only HBA context. But even mostly taskfile/BMDMA PCI IDE complying controllers may have implementation specific requirements and mechanism to reset themselves. This must be addressed by specific drivers.

OTOH, ATA/ATAPI standard describes in detail ways to reset ATA/ATAPI devices.

PATA hardware reset	This is hardware initiated device reset signalled with asserted PATA RESET- signal. There is no standard way to initiate hardware reset from software although some hardware provides registers that allow driver to directly tweak the RESET- signal.
Software reset	This is achieved by turning CONTROL SRST bit on for at least 5us. Both PATA and SATA support it but, in case of SATA, this may require controller-specific support as the second Register FIS to clear SRST should be transmitted while BSY bit is still set. Note that on PATA, this resets both master and slave devices on a channel.
EXECUTE DEVICE DIAGNOSTIC command	Although ATA/ATAPI standard doesn't describe exactly, EDD implies some level of resetting, possibly similar level with software reset. Host-side EDD protocol can be handled with normal command processing and most SATA controllers should be able to handle EDD's just like other commands. As in software reset, EDD affects both devices on a PATA bus. Although EDD does reset devices, this doesn't suit error handling as EDD cannot be issued while BSY is set and it's unclear how it will act when device is in unknown/weird state.
ATAPI DEVICE RESET command	This is very similar to software reset except that reset can be restricted to the selected device without affecting the other device sharing the cable.
SATA phy reset	This is the preferred way of resetting a SATA device. In effect, it's identical to PATA hardware reset. Note that this can be done with the standard SCR Control register. As such, it's usually easier to implement than software reset.

One more thing to consider when resetting devices is that resetting clears certain configuration parameters and they need to be set to their previous or newly adjusted values after reset.

Parameters affected are.

- CHS set up with INITIALIZE DEVICE PARAMETERS (seldom used)
- Parameters set with SET FEATURES including transfer mode setting
- Block count set with SET MULTIPLE MODE
- Other parameters (SET MAX, MEDIA LOCK...)

ATA/ATAPI standard specifies that some parameters must be maintained across hardware or software reset, but doesn't strictly specify all of them. Always reconfiguring needed parameters after reset is required for robustness. Note that this also applies when resuming from deep sleep (power-off).

Also, ATA/ATAPI standard requires that IDENTIFY DEVICE / IDENTIFY PACKET DEVICE is issued after any configuration parameter is updated or a hardware reset and the result used for further operation. OS driver is required to implement revalidation mechanism to support this.

Reconfigure transport

For both PATA and SATA, a lot of corners are cut for cheap connectors, cables or controllers and it's quite common to see high transmission error rate. This can be mitigated by lowering transmission speed.

The following is a possible scheme Jeff Garzik suggested.

If more than \$N (3?) transmission errors happen in 15 minutes,

- if SATA, decrease SATA PHY speed. if speed cannot be decreased,
- decrease UDMA xfer speed. if at UDMA0, switch to PIO4,
- decrease PIO xfer speed. if at PIO3, complain, but continue

Chapter 8. ata_piix Internals

Name

`ich_pata_cable_detect` — Probe host controller cable detect info

Synopsis

```
int ich_pata_cable_detect (struct ata_port * ap);
```

Arguments

ap Port for which cable detect info is desired

Description

Read 80c cable indicator from ATA PCI device's PCI config register. This register is normally set by firmware (BIOS).

LOCKING

None (inherited from caller).

Name

`piix_pata_prereset` — prereset for PATA host controller

Synopsis

```
int piix_pata_prereset (struct ata_link * link, unsigned long deadline);
```

Arguments

link Target link

deadline deadline jiffies for the operation

LOCKING

None (inherited from caller).

Name

`piix_set_piomode` — Initialize host controller PATA PIO timings

Synopsis

```
void piix_set_piomode (struct ata_port * ap, struct ata_device * adev);
```

Arguments

ap Port whose timings we are configuring

adev Drive in question

Description

Set PIO mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

Name

`do_pata_set_dmamode` — Initialize host controller PATA PIO timings

Synopsis

```
void do_pata_set_dmamode (struct ata_port * ap, struct ata_device *  
adev, int isich);
```

Arguments

ap Port whose timings we are configuring

adev Drive in question

isich set if the chip is an ICH device

Description

Set UDMA mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

Name

`piix_set_dmamode` — Initialize host controller PATA DMA timings

Synopsis

```
void piix_set_dmamode (struct ata_port * ap, struct ata_device * adev);
```

Arguments

ap Port whose timings we are configuring

adev um

Description

Set MW/UDMA mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

Name

`ich_set_dmamode` — Initialize host controller PATA DMA timings

Synopsis

```
void ich_set_dmamode (struct ata_port * ap, struct ata_device * adev);
```

Arguments

ap Port whose timings we are configuring

adev um

Description

Set MW/UDMA mode for device, in host controller PCI config space.

LOCKING

None (inherited from caller).

Name

`piix_check_450nx_errata` — Check for problem 450NX setup

Synopsis

```
int piix_check_450nx_errata (struct pci_dev * ata_dev);
```

Arguments

ata_dev the PCI device to check

Description

Check for the present of 450NX errata #19 and errata #25. If they are found return an error code so we can turn off DMA

Name

`piix_init_one` — Register PIIX ATA PCI device with kernel services

Synopsis

```
int piix_init_one (struct pci_dev * pdev, const struct pci_device_id  
* ent);
```

Arguments

pdev PCI device to register

ent Entry in `piix_pci_tbl` matching with *pdev*

Description

Called from kernel PCI layer. We probe for combined mode (sigh), and then hand over control to libata, for it to do the rest.

LOCKING

Inherited from PCI layer (may sleep).

RETURNS

Zero on success, or -ERRNO value.

Chapter 9. sata_sil Internals

Name

`sil_set_mode` — wrap `set_mode` functions

Synopsis

```
int sil_set_mode (struct ata_link * link, struct ata_device ** r_failed);
```

Arguments

link link to set up

r_failed returned device when we fail

Description

Wrap the libata method for device setup as after the setup we need to inspect the results and do some configuration work

Name

`sil_dev_config` — Apply device/host-specific errata fixups

Synopsis

```
void sil_dev_config (struct ata_device * dev);
```

Arguments

dev Device to be examined

Description

After the IDENTIFY [PACKET] DEVICE step is complete, and a device is known to be present, this function is called. We apply two errata fixups which are specific to Silicon Image, a Seagate and a Maxtor fixup.

For certain Seagate devices, we must limit the maximum sectors to under 8K.

For certain Maxtor devices, we must not program the drive beyond udma5.

Both fixups are unfairly pessimistic. As soon as I get more information on these errata, I will create a more exhaustive list, and apply the fixups to only the specific devices/hosts/firmwares that need it.

20040111 - Seagate drives affected by the Mod15Write bug are blacklisted The Maxtor quirk is in the blacklist, but I'm keeping the original pessimistic fix for the following reasons... - There seems to be less info on it, only one device gleaned off the Windows driver, maybe only one is affected. More info would be greatly appreciated. - But then again UDMA5 is hardly anything to complain about

Chapter 10. Thanks

The bulk of the ATA knowledge comes thanks to long conversations with Andre Hedrick (www.linux-ide.org), and long hours pondering the ATA and SCSI specifications.

Thanks to Alan Cox for pointing out similarities between SATA and SCSI, and in general for motivation to hack on libata.

libata's device detection method, `ata_pio_devchk`, and in general all the early probing was based on extensive study of Hale Landis's probe/reset code in his ATADRV driver (www.ata-atapi.com).